


Service Manual



DVR-RT500-S

ORDER NO.
RRV3033

DVD RECORDER

DVR-RT500-S DVR-RT300-S

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Type	Power Requirement	Region No.	Remarks
DVR-RT500-S	UXTLCA	AC120V	1	
DVR-RT300-S	UXTLCA	AC120V	1	




For details, refer to "Important Check Points for good servicing" .

1234

SAFETY INFORMATION

A



This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.



B

WARNING



This product contains lead in solder and certain electrical parts contain chemicals which are known to the state of California to cause cancer, birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 – Proposition 65

NOTICE

Fuse symbols  (fast operating fuse) and/or  (slow operating fuse) on PCB indicate that replacement parts must be of identical designation.

REMARQUE

Les symboles de fusible  (fusible de type rapide) et/ou  (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.

C


(FOR USA MODEL ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60 Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5 mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a ⚠ on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

IMPORTANT
THIS PIONEER APPARATUS CONTAINS
LASER OF CLASS 1.
SERVICING OPERATION OF THE APPARATUS
SHOULD BE DONE BY A SPECIALLY
INSTRUCTED PERSON.


LASER DIODE CHARACTERISTICS
MAXIMUM OUTPUT POWER : 50 mW
WAVELENGTH : 654 - 662 nm

LASER DIODE CHARACTERISTICS
MAXIMUM OUTPUT POWER : 100 mW
WAVELENGTH : 780 - 787 nm

WARNING!

DEVICE INCLUDES LASER DIODE WHICH
EMITS INVISIBLE INFRARED RADIATION
WHICH IS DANGEROUS TO EYES. THERE IS
A WARNING SIGN ACCORDING TO PICTURE
1 INSIDE THE DEVICE CLOSE TO THE LASER
DIODE.

■ LABEL CHECK



CAUTION: CLASS 3B LASER RADIATION
EXPOSURE TO THE BEAM
MAY BE DANGEROUS TO EYES.
ATTENTION: RAYON LASER CLASSE 3B
EXPOSURE AU RAYON LASER PEUT
ÊTRE DANGEREUX POUR LES YEUX.
ADVERTENCIA: RAYO LASER DE CLASE 3B
EXPOSICIÓN AL RAYO LASER PUEDE
SER PELIGROSO PARA LOS OJOS.
VERBODEN: LASER STRALING VAN
Klasse 3B kan schadelijk zijn voor
de ogen. Het is verboden het
licht van de laser te bekijken.
VERBODEN: LASER STRÅLNING AV
Klass 3B kan skadlig vara för
ögonen. Det är förbjudet att
se riktligt ljus från lasern.
VARNING: LASERSTRÅLNING AV
Klasse 3B kan være skadelig for
øynene. Det er forbudt å se
direkte på laserstrålen.
ALLA KÖNN SKÖRREK.
00000000-01

CAUTION: CLASS 3B LASER RADIATION
EXPOSURE TO THE BEAM
MAY BE DANGEROUS TO EYES.
ATTENTION: RAYON LASER CLASSE 3B
EXPOSURE AU RAYON LASER PEUT
ÊTRE DANGEREUX POUR LES YEUX.
ADVERTENCIA: RAYO LASER DE CLASE 3B
EXPOSICIÓN AL RAYO LASER PUEDE
SER PELIGROSO PARA LOS OJOS.
VERBODEN: LASER STRALING VAN
Klasse 3B kan schadelijk zijn voor
de ogen. Het is verboden het
licht van de laser te bekijken.
VERBODEN: LASER STRÅLNING AV
Klass 3B kan skadlig vara för
ögonen. Det är förbjudet att
se riktligt ljus från lasern.
VARNING: LASERSTRÅLNING AV
Klasse 3B kan være skadelig for
øynene. Det er forbudt å se
direkte på laserstrålen.
ALLA KÖNN SKÖRREK.
00000000-01

CLASS 1 LASER PRODUCT
LASER KLASSE 1

DRW2194

Additional Laser Caution

1. The ON/OFF(ON:low level,OFF:high level) status of the CLAMP signals for detecting the loading state are detected by the drive CPUs, and the design prevents laser diode oscillation when the CLAMP signal turns OFF.
In normal operation, if no disc is clamped, the laser diode oscillation is disabled.
However, the interlock does not always operate in the test mode.
2. When the cover is opened, close viewing of the objective lens with the naked eye will cause exposure to a Class 3A laser beam.

[Important Check Points for Good Servicing]

In this manual, procedures that must be performed during repairs are marked with the below symbol.
Please be sure to confirm and follow these procedures.

1. Product safety



Please conform to product regulations (such as safety and radiation regulations), and maintain a safe servicing environment by following the safety instructions described in this manual.

- ① Use specified parts for repair.

Use genuine parts. Be sure to use important parts for safety.

- ② Do not perform modifications without proper instructions.

Please follow the specified safety methods when modification(addition/change of parts) is required due to interferences such as radio/TV interference and foreign noise.

- ③ Make sure the soldering of repaired locations is properly performed.

When you solder while repairing, please be sure that there are no cold solder and other debris.
Soldering should be finished with the proper quantity. (Refer to the example)

- ④ Make sure the screws are tightly fastened.

Please be sure that all screws are fastened, and that there are no loose screws.

- ⑤ Make sure each connectors are correctly inserted.

Please be sure that all connectors are inserted, and that there are no imperfect insertion.

- ⑥ Make sure the wiring cables are set to their original state.

Please replace the wiring and cables to the original state after repairs.
In addition, be sure that there are no pinched wires, etc.

- ⑦ Make sure screws and soldering scraps do not remain inside the product.

Please check that neither solder debris nor screws remain inside the product.

- ⑧ There should be no semi-broken wires, scratches, melting, etc. on the coating of the power cord.

Damaged power cords may lead to fire accidents, so please be sure that there are no damages.
If you find a damaged power cord, please exchange it with a suitable one.

- ⑨ There should be no spark traces or similar marks on the power plug.

When spark traces or similar marks are found on the power supply plug, please check the connection and advise on secure connections and suitable usage. Please exchange the power cord if necessary.

- ⑩ Safe environment should be secured during servicing.

When you perform repairs, please pay attention to static electricity, furniture, household articles, etc. in order to prevent injuries.
Please pay attention to your surroundings and repair safely.

2. Adjustments



To keep the original performance of the products, optimum adjustments and confirmation of characteristics within specification.
Adjustments should be performed in accordance with the procedures/instructions described in this manual.

3. Lubricants, Glues, and Replacement parts



Use grease and adhesives that are equal to the specified substance.
Make sure the proper amount is applied.

4. Cleaning



For parts that require cleaning, such as optical pickups, tape deck heads, lenses and mirrors used in projection monitors, proper cleaning should be performed to restore their performances.

5. Shipping mode and Shipping screws



To protect products from damages or failures during transit, the shipping mode should be set or the shipping screws should be installed before shipment. Please be sure to follow this method especially if it is specified in this manual.

CONTENTS

SAFETY INFORMATION.....	2
1. SPECIFICATIONS	7
2. EXPLODED VIEWS AND PARTS LIST	10
2.1 PACKING	10
2.2 EXTERIOR SECTION	12
2.3 DECK ASSY (TOP SECTION)	14
2.4 DECK ASSY (BOTTOM SECTION).....	16
2.5 WIRING CABLE.....	18
3. BLOCK DIAGRAM AND SCHEMATIC DIAGRAM	20
3.1 BLOCK DIAGRAM	20
3.1.1 OVERALL BLOCK DIAGRAM	20
3.1.2 MPEG BLOCK BLOCK DIAGRAM	21
3.1.3 Y/C AUDIO / CCD / HEAD AMP BLOCK DIAGRAM	22
3.1.4 SYSTEM CONTROL BLOCK DIAGRAM.....	23
3.1.5 REGULATOR BLOCK DIAGRAM	24
3.1.6 OPERATION / DISPLAY BLOCK DIAGRAM	25
3.1.7 HiFi / DEMODULATOR BLOCK DIAGRAM	26
3.1.8 TUNER / JACK BLOCK DIAGRAM.....	27
3.1.9 AV SW BLOCK DIAGRAM	28
3.1.10 POWER BLOCK DIAGRAM	29
3.2 OVERALL WIRING DIAGRAM	30
3.3 DVD/HD MPEG PCB ASSY(1/6)	32
3.4 DVD/HD MPEG PCB ASSY(2/6)	34
3.5 DVD/HD MPEG PCB ASSY(3/6)	36
3.6 DVD/HD MPEG PCB ASSY(4/6)	38
3.7 DVD/HD MPEG PCB ASSY(5/6)	40
3.8 DVD/HD MPEG PCB ASSY(6/6)	42
3.9 VCR MT PCB ASSY(1/7).....	44
3.10 VCR MT PCB ASSY(2/7).....	46
3.11 VCR MT PCB ASSY(3/7).....	48
3.12 VCR MT PCB ASSY(4/7).....	50
3.13 VCR MT PCB ASSY(5/7).....	52
3.14 VCR MT PCB ASSY(6/7).....	54
3.15 VCR MT PCB ASSY(7/7).....	56
3.16 POWER PCB ASSY	58
3.17 OPEARTION PCB ASSY	60
3.18 WAVE FORMS.....	61
4. PCB CONNECTION DIAGRAM	66
4.1 DVD/HD MPEG PCB ASSY.....	66
4.2 VCR MT PCB ASSY	70
4.3 POWER PCB ASSY	74
4.4 OPERATION PCB ASSY	75
5. PCB PARTS LIST	76
6. ADJUSTMENT	79
6.1 SERVICING FIXTURES AND TOOLS.....	79
6.2 ADJUSTMENT ITEMS AND NECESSARY ADJUSTMENT POINTS	80
6.3 SERVICE MODE LIST.....	82
6.4 CONFIRMATION OF HOURS USED	83
6.5 PREVENTIVE CHECKS AND SERVICE INTERVALS	84
6.6 MECHANICAL ADJUSTMENTS.....	85
6.7 ELECTRICAL ADJUSTMENTS.....	89
6.8 WHEN REPLACING NEW DVD LOADER.....	91
6.9 WHEN REPLACING EEPROM (MEMORY) IC.....	92
7. GENERAL INFORMATION	93
7.1 RE-WRITE FOR DVD FIRMWARE.....	93
7.2 MEASUREMENT OF ERROR RATE.....	94
7.3 POWER ON SEQUENCE.....	95
7.4 DISC REMOVAL METHOD	96
7.5 TAPE REMOVAL METHOD AT NO POWER SUPPLY	96
7.6 PARENTAL CONTROL-RATING LEVEL.....	97
7.7 TRAY LOCK.....	97
7.8 DISASSEMBLY	98
7.9 CAUTIONS ON DIASSEMBLING AND ASSEMBLING	106
7.10 KEY TO ABBREVIATIONS	108
7.11 DISC/CONTENT FORMAT	109

7.12 CLEANING.....	111
8. PANEL FACILITIES	112

A

■

B

■

C

■

D

■

E

■

F

1. SPECIFICATIONS

G-1	Outline of the product		DVD-R/-RW Video Recorder & VHS Player/Recorder
G-2	DVD System	Color System	NTSC
		Disc Format	Rec Play DVD-R/-RW, DVD-Video, CD-DA, CD-R/-RW
		Disc Diameter	120 mm, 80 mm
		Deck	Disc Loading System Motor Front Disc Loading 3 Motors
		Pick up	1-Lens 2-Beams System
		Rec Time (Approx.) at 4.7 GB Disc	XP SP LP SLP 1 hour at 10 Mbps 2 hour at 5 Mbps 4 hour at 2.5 Mbps 6 hour at 1.6 Mbps
		Playback time (Max)	DVD 1-Layer DVD 2-Layer CD VIDEO CD 135 min (4.7 GB) 245 min (8.5 GB) 74 min --
		Search speed	Actual Fwd 4 step 2-45 times (DVD) 4-40 times (CD)
			Actual Rev 4 step 2-45 times (DVD) 4-40 times (CD)
		Slow speed	Actual Fwd 1/8-1/2 times --
			Actual Rev -- --
G-3	VCR System	System	VHS Player / Recorder
		Video System	NTSC
		Hi-Fi STEREO	Yes
		NTSC PB (PAL 60Hz)	No
		Deck	DECK Loading System Motor OVD-7 Front 3
		Heads	Video Head FM Audio Head Audio / Control Erase (Full Track Erase) 4 Head 2 Head Mono / Yes Yes
		Tape Speed	Rec PAL NTSC SP/SLP
			Play PAL NTSC SP/LP/SLP
		Fast Forward / Rewind Time (Approx.) at 25°C with Cassette	FF : 1'48" / REW : 1'48" T-120
		Forward / Reverse Picture Search	NTSC or PAL-M PAL or SECAM SP/LP/SLP = 3x, 5x / 7x, 9x / 9x, 15x --
		Frame Advance	Yes
		Slow Speed	1/10

6.3 SERVICE MODE LIST

To enter one of the Sub-Service modes, hold a designated key on the unit pressed for a specified period of time while holding another designated key on the unit or on the remote control unit pressed.

Mode of the Unit	Key on the Unit	Key on the Unit	Specified Period (sec)	Description
VCR	FF	CH+	2	For (1) initial setting of the μ -CON on the VCR side, (2) confirmation of initial settings for the Memory IC, and (3) displaying the accumulated time of playback and recording on the screen.
VCR	PLAY	CH+	2	Initialization to the state at shipment Note: Do NOT use this mode during normal servicing. This mode will reset the time setting, channel setting, and the accumulated time of playback/recording.
VCR (Playback)	CH+	CH-	2	For setting tracking to the center value Note: You can enter this mode by holding the ATR key on the remote control unit pressed for 2 seconds.
VCR (Playback)	REC/OTR	DVD/VCR	2	For automatic adjustment of the PG shifter
VCR	CH+	REC/OTR	2	For entering Service mode Entering this mode disables the EOT/BOT/reel sensor and enables the VCR section of the unit to operate even if a tape is not loaded.
VCR	STOP	CH+	2	For entering DVD-Audio-Level/Separation Adjustment mode
DVD	CH-	DVD/VCR	2	For displaying information
VCR	CH-	S-BY/ON	2	For entering Operation-of-Only-VCR-Section mode Note: In this mode, you cannot switch to DVD mode even if connection of the DVD section has been made.

The following Sub-Service modes can be entered by first holding the designated key on the remote control unit pressed then pressing another designated key on the unit.


Mode of the Unit	Key on the Remote Control Unit	Key on the Unit	Specified Period (sec)	Description
DVD	0	STOP	2	For setting and unlocking the TRAY Lock. This mode functions cyclically.
DVD (NO DISC)	2	STOP	2	F/W Writing mode
DVD	6	STOP	2	For initial setting of μ -CON on the DVD side
DVD (NO DISC)	7	STOP	2	For canceling Parental Lock Note: This mode functions only when a disc is not loaded in DVD mode
DVD (NO DISC)	8	STOP	2	For entering Region-Code Writing mode
DVD (Playback, NO DISC)	9	STOP	2	For displaying Loader Information and error rates

For switching the RF output channels (CH 3/4)

While the unit is off, hold the 3 or 4 key on the remote control unit pressed for at least 3 seconds.

● Accessories


- Transmitter ×1
(076R0JZ010)




- Dry cell batteries ×2
(AAA/R03)



- RF antenna cable ×1
(06CPL02006)



- RCA Pin cable(L=1.2m) ×1
(red/white/yellow)
(06CPBA2003)




- Warranty Card
- Operating Instructions


1234

2. EXPLODED VIEWS AND PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Screws adjacent to ▼ mark on product are used for disassembly.
- For the applying amount of lubricants or glue, follow the instructions in this manual.
(In the case of no amount instructions, apply as you think it appropriate.)

2.1 PACKING



PACKING parts List


Mark No.	Description	Part No.	Mark No.	Description	Part No.
1	Gift Sheet	791WHA0100	9	Warning Sheet	J2D30928A
2	Package,Back	792WHA0519	10	Polyethylene bag,Instruction	JB5UD200
3	Package,Front	792WHA0574			
4	Gift Box	See Contrast table (2)	11	Transmitter (VXX2949)	076R0JZ010
5	Pad,DVD/VR (155 x 250)	795WCA0662	12	RF Antenna Cable	06CPL02006
			13	RCA Pin Cable	06CPBA2003
6	••••••••		NSP 14	Battery Man Gan	1412004013
7	Instruction Book (English)	J2D30901A	NSP 15	Polyethylene Bag	Y817041000
8	Guarantee Card	J2D30902A			

(2) CONTRAST TABLE

DVR-RT500-S/UXTLCA and DVR-RT300-S/UXTLCA are constructed the same except for the following:

Mark	No.	Symbol and Description	DVR-RT500-S /UXTLCA	DVR-RT300-S /UXTLCA
	4	Gift Box	793WCD1572	793WCD1587

2.2 EXTERIOR SECTION



EXTERIOR SECTION parts List

Mark No.	Description	Part No.	Mark No.	Description	Part No.	
1	DVD/HD MPEG PCB Assy	See Contrast table (2)	31	Shield, Case Head Amp	752WSA0230	
2	VCR MT PCB Assy	A2D309A010	32	Spring, Earth Head Amp	753WUAA006	A
3	OPERATION PCB Assy	A2D309A270	33	Holder, End Sensor	85OP700038	
4	POWER PCB Assy	A2D309A240				
5	DRIVE Assy R7R (for Service)	VXX2976	34	Sheet, Rating	See Contrast table (2)	
			35	Sheet, Jack	See Contrast table (2)	
6	DECK Assy	A2D309A420A	36	Cover, AC Head	752WSA0275	
7	Front Cabi Assy	See Contrast table (2)	37	Shield, COMPO	752WSA0290	
8	Cabinet, Front	See Contrast table (2)	38	Shield, MPEG	752WSA0391	
NSP 9	Plate, Display	See Contrast table (2)				
10	Flap, VCR	712WPJ0877	39	Shield, Jack	752WUA0008	
			40	Angle, DVD (L)	761WSA0150	
11	Flap, DVD	712WPQ0008	41	Angle, DVD (R)	761WSA0151	B
12	Cover, LED	713WPA0332	42	Holder, Top	701WPA0781	
13	Glass, LED	713WPA0333	43	Cabinet, Top	702WSB0092	
14	Sheet, LED	7230007689				
15	Stopper, Button	738WPA0105	44	Cushion (20 x 5 x T1)	800WFA0055	
			45	Cushion 65TS10-10 (17.5 x 20 x 14)	8965TS1017	
16	Button, Frame1	738WPB0040	46	Cushion 65TS10-5 (15 x 20 x 16)	8965TS1015	
17	Button, Frame2	738WPB0041				
18	Spring, DVD-Flap	742WKA0001	47	POP Label	7230007860	
19	Spring, Flap	743WKA0042	48	Holder, DVD	713WPA0337	C
20	Cushion, Leg	800WFA0045	49	Sheet, Serial	7220001196	
			NSP 50	Tape	ZTA-570F-190BK	
21	Bottom Cabi Assy	7G7610007A	51	Screw	8109130B9U	
22	Plate, Bottom	702WSA0227				
23	Angle, Center	761WSA0175	52	Screw	810923070U	
24	Shield, Deck Assy	7G7610005D	53	Screw	8109130A0U	
25	Sheet (149.4 x 14 x T14)	7230007819	54	Screw	810923080U	
			55	Screw	8109K3060U	
26	Shield, Deck	752WSA0437	56	Screw	810723040U	
27	Cushion 65TS10.5-20 (40 x 15 x 6)	8965TS2040				
28	Cushion 65TS10.5-20 (20 x 15 x 12)	8965TS2020	57	Screw	8110E2680U	D
			58	Screw	811022680U	
29	Holder, Deck	701WPA0686	59	Screw	810223060U	
30	Holder, Deck	701WPA0751				


(2) CONTRAST TABLE

DVR-RT500-S/UXTLCA and DVR-RT300-S/UXTLCA are constructed the same except for the following:

Mark	No.	Symbol and Description	DVR-RT500-S /UXTLCA	DVR-RT300-S /UXTLCA
NSP	1	DVD/HD MPEG PCB Assy	A2D309AB10*	A2D311AB10*
	7	Front Cabi Assy	7A7010037C	7A7010040C
	8	Cabinet, Front	701WPJ1285	701WPJ1308
	9	Plate, Display	711WPD0662	711WPD0663
	34	Sheet, Rating	7226310001	7226310002
	35	Sheet, Jack	7230007843	7230007844

* The DVD/HD MPEG PCB Assy difference is only EEPROM (IC4002) setting data. Refer to P.92.

2.3 DECK ASSY (TOP SECTION)



DECK ASSY (TOP SECTION) parts List

Mark No.	Description	Part No.	Mark No.	Description	Part No.	
1	Pinch Roller Block (VA)	85OA400240	50	Screw/Washer (A)	810A130404	
2	AHC Assy	85OA500026				A
3	Worm	85OP600581	51	Screw/Washer (A)	810A126504	
4	Base, AC Head	85OP500083	52	Polyslider Washer	82Q264713N	
5	Spring, AC Head	85OP800324	53	Screw	8107226604	
6	Main Chassis Assy	85OA000516				
7	Arm Idler Assy	85OA200090				
8	Inclined Base T Unit 3S	85OA400223				
9	P5 Arm Assy 2	85OA400232				
10	Tension Arm Assy 2	85OA400235				
11	Inclined Base S Unit	85OA400231				B
12	Spring, Locker	85OP800367				
13	Cass, Holder	85OP900736				
14	Cass, Side L	85OP900748				
15	Cass, Side R	85OP900749				
16	Locker, R	85OP900739				
17	Link Unit	85OA900228				
18	Post, Cass Guide	85OP000496				
19	Reel, S (S)	85OP200316				
20	Reel, T (S)	85OP200317				C
21	Gear, Idler	85OP200308				
22	Holder, Tension	85OP400492				
23	Cap. P4	85OP400520				
24	Band, Tension	85OP400542				
25	Connect, Tension	85OP400533				
26	Arm, Brake T	85OP600573				
27	Band, Brake T	85OP600584				
28	Spring, Tension	85OP800322				
29	Spring, Brake T	85OP800360				
30	Lever, Link	85OP900743				D
31	Lever, Flap	85OP900744				
32	Cass, Opener	85OP900745				
33	Reflector, LED	85OP700035				
34	Bracket, Top 3V	85OP900746				
35	Cord Jumper (CD1501)	122H071704				
36	Cord Jumper (CD1502)	122Y021902				
37	Head (Audio Control)(H5001)	1523Q91003				
38	Head (Full Erase)(H5002)	1543Q02014				E
⚠ 39	Motor, Loading (M101)	1596S98002				
40	Micro Motor (M2003)	1589S11020				
⚠ 41	Cylinder Unit Assy (UN4001)	A5L1046500				
42	Cord Jumper (CD102)	?????				
43					
44					
45					
46	Screw	8107226804				
47	Screw	8107226404				F
48	Screw	8102120604				
49	Screw	8109126604				

4



5

6

7

8

DECK ASSY (BOTTOM SECTION) parts List

Mark No.	Description	Part No.
1	Belt, Capstan (S)	85OP200290
2	Main Chassis Assy	85OA000516
3	Clutch Assy	85OA200089
4	Loading Arm S Unit	85OA300065
5	Loading Arm T Unit	85OA300066
6	Gear, Clutch	85OP200311
7	Gear, Coupling	85OP200312
8	Lever, Clutch	85OP200313
9	Gear, Main Loading	85OP300194
10	Lever, Tension	85OP400490
11	Cam, Pinch Roller	85OP600577
12	Cam, Main	85OP600578
13	Rod, Main	85OP600579
14	Gear, Joint	85OP600582
15	Spring, Coupling	85OP800355
16	Spring, Ring	85OP800356
17	Holder, Capstan	85OP400549
18	Cord Jumper (CD1501)	122H071704
19	Cord Jumper (CD1502)	122Y021902
⚠ 20	Capstan DD Unit (M2001)	1510S98042
21	Screw	8107226804
22	E-Ring	83ETW30000
23	Screw	8109126604
24	Polyslider Washer	82P184505N

A

B

C

D

E

F

2.5 WIRING CABLE

A


B

C

D

E

F



* All cables are ASSY parts.



5



6



7



8



A



B



C



D



E



F



5



6



7




8




DVR-RT500-S


3.1.1 OVERALL BLOCK DIAGRAM




3.1.2 MPEG BLOCK BLOCK DIAGRAM




3.1.3 Y/C AUDIO / CCD / HEAD AMP BLOCK DIAGRAM




3.1.4 SYSTEM CONTROL BLOCK DIAGRAM




3.1.5 REGULATOR BLOCK DIAGRAM



3.1.6 OPERATION / DISPLAY BLOCK DIAGRAM




3.1.7 HiFi / DEMODULATOR BLOCK DIAGRAM



28



3.1.10 POWER BLOCK DIAGRAM



DVR-RT500-S

3.2 OVERALL WIRING DIAGRAM

A

B


C



D

E


F

DRIVE ASSY R7R
(VXX2976)



- When ordering service parts, be sure to refer to "EXPLODED VIEWS and PARTS LIST" or "PCB PARTS LIST".
- The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
-  : The power supply is shown with the marked box.

D OPERATION PCB ASSY (A2D309A270)



4

- **AV ENCODER BLOCK**



A 2/6

- **MPEG BLOCK**

A 3/6




A 2/6



△

F






1234

3.6 DVD/HD MPEG PCB ASSY(4/6)

A

A4/6

DVD/HD MPEG PCB ASSY
(DVR-RT500-S : A2D309AB10)
(DVR-RT300-S : A2D311AB10)
● ATAPI BLOCK






3.7 DVD/HD MPEG PCB ASSY(5/6)

A 5/6 DVD/HD MPEG PCB ASSY (DVR-RT500-S : A2D309AB10) (DVR-RT300-S : A2D311AB10)

● AUDIO BLOCK




AUDIO SIGNAL
 AUDIO SIGNAL(PB)
 TUNER AUDIO SIGNAL


CAUTION: DIGITAL TRANSISTOR



FROM/TO AV I/O




3.8 DVD/HD MPEG PCB ASSY(6/6)



A 6/6 DVD/HD MPEG PCB ASSY (DVR-RT500-S : A2D309AB10) (DVR-RT300-S : A2D311AB10)

● AV IN/OUT BLOCK



B 7/7
CP8301

B 7/7
CP8302

B 7/7
CP8303

B 4/7
CP1703

◀ COMPONENT SIGNAL(U)
 ◀ COMPONENT SIGNAL(V)
 ▶ PLAYBACK LUMINANCE SIGNAL

3.9 VCR MT PCB ASSY(1/7)

B 1/7

VCR MT PCB ASSY
(A2D309A010)

● Y/C/AUDIO/CCD/HEAD AMP BLOCK

FROM/TO REGULATOR

B 4/7

P.CON+5V
GND

FROM/TO HI-FI/DEMODULATOR

FSC
NORMAL_A_IN
NORMAL_A_OUT
HF1
HF_COM
HF2
GND

B 6/7

FROM/TO CYL

CP101

TOC-C09X-A1

9 HF1 (R)
8 HF COM
7 HF2 (L)
6 SP-CH1 (R)
5 SP COM
4 SP-CH2 (L)
3 EP/LP-CH1 (R)
2 EP/LP COM
1 EP/LP-CH2 (L)

To
UN4001

FROM/TO HEAD AUDIO CONTROL

CP102

IMS-A9604S-06C

6 AUDIO REC
5 AUDIO PB
4 CTL+
3 CTL-
2 AE HEAD(+)
1 AE HEAD(-)

To
H5001

TO FE HEAD

CP103

B2013H02-2P

2 FE HEAD(GND)
1 FE HEAD(HOT)

To
H5002

NORMAL A IN

R105 10K

L103 100H

P.CON+5V

V.REC ST-H

SW Q103 DTA124EKA

5.0

0

5.0

COIL BIAS OSC L101 1626009

6.3V 220 YK

C104

0.015 B

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0

L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK

C107

0.015 B

R107 3.3K

0.2

BIAS OSC Q104 KTC3203_Y

6.3V 47 KA

C110

0.1 B

R108 22K

5.0

BIAS CTL Q105 KTA1266

5.0


L102 100H 0305

0.2

C106

0.01 B

6.3V 220 YK



△






- **SYSCON AMP BLOCK**



3.11 VCR MT PCB ASSY(3/7)

B3/7 VCR MT PCB ASSY (A2D309A010)


● TUNER/JACK BLOCK



CAUTION: DIGITAL TRANSISTOR

CAUTION: DIGITAL TRANSISTOR







3.12 VCR MT PCB ASSY(4/7)


B 4/7 VCR MT PCB ASSY (A2D309A010)

● REGULATOR BLOCK






CAUTION: DIGITAL TRANSISTOR




CAUTION: DIGITAL TRANSISTOR




1 2 3 4

3.13 VCR MT PCB ASSY(5/7)

B 5/7 VCR MT PCB ASSY
(A2D309A010)
● DISPLAY BLOCK







3.14 VCR MT PCB ASSY(6/7)

B 6/7 VCR MT PCB ASSY (A2D309A010)

● Hi-Fi/DEMODULATOR BLOCK






- **AV SW BLOCK**






3.16 POWER PCB ASSY

C POWER PCB ASSY (A2D309A240)




* The parts except mark cannot be changed. On that occasion, replace whole Assy.



1 2 3 4

3.17 OPEARTION PCB ASSY

A **D** OPERATION PCB ASSY (A2D309A270)




- C
- SWITCHES**
- SW681 REW/RWV
 - SW682 STOP
 - SW683 FF/CUE
 - SW684 REC/OTR
 - SW685 PLAY
 - SW686 OPEN/CLOSE
 - SW687 CH DOWN
 - SW688 CH UP

B 5/7
CP651

3.18 WAVE FORMS


Note: The encircled numbers denote measuring point in the schematic diagram.

A DVD/HD MPEG PCB ASSY




A


16 IC4005-pin 38 (PCLK)
V: 500mV/div. H: 5nsec/div.



21 IC7301-pin 11 (I55_AMCLK)
V: 1.0V/div. H: 20nsec/div.



26 CP7302-pin 13 (C_OUT)
V: 500mV/div. H: 10μsec/div.




B


17 IC7301-pin 4 (ABCLKO)
V: 1.0V/div. H: 100nsec/div.



22 IC7301-pin 13 (I55_ALRCLK)
V: 1.0V/div. H: 5μsec/div.




27 CP7301-pin 17 (Y_VIDEO_IN)
V: 200mV/div. H: 10μsec/div.




C


18 IC7301-pin 5 (VADDIS_AMCLK)
V: 1.0V/div. H: 20nsec/div.



23 IC7301-pin 27 (DAC_R)
V: 1.0V/div. H: 200μsec/div.




28 CP7301-pin 19 (C_VIDEO_IN)
V: 200mV/div. H: 10μsec/div.




D


19 IC7301-pin 7 (ALRCLKO)
V: 1.0V/div. H: 5μsec/div.



24 IC7301-pin 26 (DAC_L)
V: 1.0V/div. H: 200μsec/div.




29 IC7302-pin 6 (TU_VIDEO)
V: 200mV/div. H: 10μsec/div.




E


20 IC7301-pin 10 (I55_ABCLK)
V: 1.0V/div. H: 100nsec/div.



25 CP7302-pin 9 (Y_OUT)
V: 500mV/div. H: 10μsec/div.




30 IC7302-pin 4 (COMPOSITE_IN)
V: 200mV/div. H: 10μsec/div. EE




F

B VCR MT PCB ASSY


③① CP7302-pin 3 (V/R_OUT)
V: 500mV/div. H: 10μsec/div.




③② CP7302-pin 5 (U/B_OUT)
V: 500mV/div. H: 10μsec/div.




③③ CP7302-pin 7 (Y/G_OUT)
V: 500mV/div. H: 10μsec/div.




③④ CP7302-pin 11 (CVBS_OUT)
V: 500mV/div. H: 10μsec/div.




① IC101-pin 49 (Xtal) VCR PLAY
V: 100mV/div. H: 100nsec/div.




② CP102-pin 2 (AE HEAD +) VCR REC
V: 20V/div. H: 5μsec/div.




③ IC101-pin 10 (NORMAL_A_OUT)
VCR PLAY
V: 20mV/div. H: 200μsec/div.




④ TP101 (V. ENV) VCR PLAY
V: 10mV/div. H: 5msec/div.




⑤ IC101-pin 26 VCR PLAY
V: 500mV/div. H: 10μsec/div.




⑥ IC3001-pin 76 (X1) VCR PLAY
V: 500mV/div. H: 10μsec/div.




⑦ IC3001-pin 80 (OSC2) VCR PLAY
V: 1.0V/div. H: 20nsec/div.




⑧ IC3001-pin 104 (D_FG/PG) VCR PLAY
V: 500mV/div. H: 500μsec/div.



⑨ IC3001-pin 105 (H. SW) VCR PLAY
V: 2.0V/div. H: 10msec/div.




⑩ IC3001-pin 8 (CTL_SMT(I)) VCR PLAY
V: 1.0V/div. H: 10msec/div.




A


⑪ IC3001-pin 9 (CAP_FG) VCR PLAY
V: 1.0V/div. H: 200μsec/div.



⑫ IC701-pin 57 (HIFI_A_OUT_L) VCR PLAY
V: 200mV/div. H: 1msec/div.




⑬ IC8307-pin 2 (Xtal) VCR PLAY
V: 100mV/div. H: 500nsec/div.




B


⑭ IC3001-pin 22 (4FSCIN/2FSCIN) VCR PLAY
V: 1.0V/div. H: 20nsec/div.



⑮ IC701-pin 53 (HIFI_A_OUT_R) VCR PLAY
V: 200mV/div. H: 1msec/div.




⑯ IC8304-pin 7 (F/R_VIDEO) VIDEO IN
V: 200mV/div. H: 10μsec/div.




C


⑰ Q3002-pin 3 (REEL_T) VCR PLAY
V: 1.0V/div. H: 500msec/div.



⑱ IC701-pin 30 (HIFI_ENV.) VCR PLAY
V: 200mV/div. H: 2msec/div.




⑲ IC8305-pin 7 (TU/VCR_VIDEO) TUNER IN
V: 20mV/div. H: 10μsec/div.




D


⑳ Q3001-pin 3 (REEL_S) VCR PLAY
V: 1.0V/div. H: 500msec/div.



㉑ IC701-pin 27 (HIFI_H_SW) VCR PLAY
V: 1.0V/div. H: 10msec/div.




㉒ IC8309-pin 7 (F/R_V_IN) VIDEO IN
V: 200mV/div. H: 10μsec/div.




E


㉓ J8005-pin 5 (V) VCR PLAY
V: 200mV/div. H: 10μsec/div.



㉔ IC701-pin 45 (FSC) VCR PLAY
V: 200mV/div. H: 100nsec/div.




㉕ IC8308-pin 7 (SW_V_OUT) VCR PLAY
V: 50mV/div. H: 10μsec/div.




F

C POWER PCB ASSY


26 IC8301-pin 1 (DVD_A_OUT_L)
DVD PLAY
V: 100mV/div. H: 200μsec/div.




31 CP8301-pin 14 (ST_A_OUT_R)
TUNER IN
V: 200mV/div. H: 200μsec/div.




1 Foot of R516 DVD PLAY
V: 50V/div. H: 5μsec/div.




27 IC8301-pin 8 (DVD_A_OUT_R)
DVD PLAY
V: 100mV/div. H: 200μsec/div.




2 Q501-Gate DVD PLAY
V: 1.0V/div. H: 1μsec/div.




28 IC8303-pin 7 (F/R_VIDEO_C) VIDEO IN
V: 20mV/div. H: 10μsec/div.



29 IC8302-pin 7 (F/R_VIDEO_Y) VIDEO IN
V: 20mV/div. H: 10μsec/div.



30 CP8301-pin 16 (ST_A_OUT_L)
TUNER IN
V: 20mV/div. H: 200μsec/div.




4. PCB CONNECTION DIAGRAM

4.1 DVD/HD MPEG PCB ASSY

SIDE A

A DVD/HD MPEG PCB ASSY



SIDE B

A

B


C

D

E

F

A DVD/HD MPEG PCB ASSY



IC4006

IC7302

IC4008

IC4007

CP4007



A

△


- **Parts mounted view**

VCR MT PCB ASSY

2 CP8:



4



SIDE A

DRIVE ASSY FAN
R7R MOTOR




4.4 OPERATION PCB ASSY

SIDE A

SIDE A

D OPERATION PCB ASSY



D

D

5. PCB PARTS LIST

NOTES: ●Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

●The Δ mark found on some component parts indicates the importance of the safety factor of the part.

Therefore, when replacing, be sure to use parts of identical designation.

●When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560 Ω \rightarrow 56 x 10¹ \rightarrow 561 RD1/4PU561J

47k Ω \rightarrow 47 x 10³ \rightarrow 473 RD1/4PU473J

0.5 Ω \rightarrow R50 RN2H R50K

1 Ω \rightarrow 1R0 RS1P 1R0K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62k Ω \rightarrow 562 x 10¹ \rightarrow 5621 RN1/4PC5621F

Mark No. Description Part No.

LIST OF ASSEMBLIES

1..DVD/HD MPEG PCB ASSY (RT500) A2D309AB10

1..DVD/HD MPEG PCBA SSY (RT300) A2D311AB10

1..VCR MT PCB ASSY A2D309A010

1..POWER PCB SUPPLY ASSY A2D309A240

1..OPERATION PCB ASSY A2D309A270

Mark No. Description Part No.

SEMICONDUCTORS

IC101 IC LA71206M-MPB I03F3206M0

IC651 IC PT6315 IF4K063150

IC701 IC AN3663FBP I01F63FBP0

IC801 IC AN5829S I01FF58290

Δ IC1701 IC LM2902DR IOCF0902D

IC3001 IC OEC0142B I54F50142B

IC3003 IC XC61CN3102SR IE2F031020

NSP IC3099 MEMORY DATA S-24C08AFJA-TB-0 S2D309AE01

* This is NOT SERVICE PART because the Unit does not work properly when replacing this part. Please replace VCR MTB Assy when replacement of this part is required.

IC4001 IC ZR36750E ICQM067500

IC4002 MEMORY DATA BR24L16FJ-WE2 S2D309AE02
(for DVR-RT500-S)

IC4002 MEMORY DATA BR24L16FJ-WE2 S2D309AE03
(for DVR-RT300-S)

IC4003 IC BD5229G I97F052290

IC4004 IC MT48LC8M16A2P-7E IF6J08M167

IC4005 IC MT48LC8M16A2P-7E IF6J08M167

IC4006 MEMORY DATA LH28F640BFHE-PTTL80 S2D309AF01

IC4007 IC HY57V561620CT-7 ICLJ020CT7

IC4008 IC HY57V561620CT-7 ICLJ020CT7

IC4009 IC ZR35100 ICQK051000

IC4010 IC SN74LVC1G125DCKR I5CJ0G1250

IC7301 IC WM8776SEFT/R IFJK087760

IC7302 IC MM1501XNRE IOUF015010

IC8301 IC NJM4580M(Te1) IOQJ045800

IC8302 IC NJM2534V(Te2) IOQF02534V

IC8303 IC NJM2534V(Te2) IOQF02534V

IC8304 IC NJM2534V(Te2) IOQF02534V

IC8305 IC NJM2534V(Te2) IOQF02534V

IC8307 IC LA7210 IO3S072100

IC8308 IC NJM2246M-TE1 IOQF02246M

IC8309 IC NJM2246M-TE1 IOQF02233M

Q101 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q102 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Mark No. Description Part No.

Q103 COMPOUND TRANSISTOR DTA124EKAT146 TPYJC05001

Q104 TRANSISTOR,SILICON KTC3203S_Y TCAT032034

Q105 TRANSISTOR,SILICON KTA1266 TAATA12660

Q106 TRANSISTOR,SILICON KTA1504S_Y_RTK TAAA1504SY

Q107 TRANSISTOR,SILICON KTA1504S_Y_RTK TAAA1504SY

Q109 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q301 TRANSISTOR,SILICON KTC3198 TAAA1504SY

Q302 COMPOUND TRANSISTOR DTA124EKAT146 TNJYJC05001

Q303 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q651 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q652 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q1701 COMPOUND TRANSISTOR DTA143EKAT146 TPYJA05001

Q1703 COMPOUND TRANSISTOR DTA124EKAT146 TPYJC05001

Q1706 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q1707 COMPOUND TRANSISTOR DTA124EKAT146 TPYJA05001

Q1708 TRANSISTOR,SILICON KTB1151 TBA0011510

Q1709 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q1710 TRANSISTOR,SILICON KTC3203 TCAT032034

Q1711 TRANSISTOR,SILICON KTC3203 TCAT032034

Q1712 TRANSISTOR,SILICON KTC3875S TCAA3875SY

Q1713 TRANSISTOR,SILICON KTB1151 TBA0011510

Q1716 TRANSISTOR,SILICON KTC3209 TCAT032034

Q1717 COMPOUND TRANSISTOR DTA124EKAT146 TNYJC05001

Q1720 TRANSISTOR,SILICON KTC3209 TCAT03209Y

Q1721 TRANSISTOR,SILICON KTA1281 TAAT0128Y

Q1722 COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001

Q1723 TRANSISTOR,SILICON KTA1271 TAAT012714

Q1724 COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001

Q3001 PHOTO COUPLER RPI-303 2700690

Q3002 PHOTO COUPLER RPI-303 2700690

Q3004 PHOTO COUPLER RPI-352C40N 2700680

Q3005 PHOTO COUPLER RPI-352C40N 2700680

Q3006 PHOTO TRANSISTOR ST-304L 0000M00390

Q3007 COMPOUND TRANSISTOR DTA143EKAT146 TPYJA05001

Q3008 PHOTO TRANSISTOR ST-304L 0000M00390

Q7301 COMPOUND TRANSISTOR KRC103SRTK TNAAC05002

Q8001 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q8002 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q8003 COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001

Q8004 COMPOUND TRANSISTOR DTA143EKAT146 TPYJA05001

Q8005 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q8006 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q8007 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

Q8008 COMPOUND TRANSISTOR DTC124EKAT146 TPYJC05001

Q8009 COMPOUND TRANSISTOR DTC124EKAT146 TPYJC05011

Q8010 TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY

5	6
Mark No.	Description Part No.
Q8012	COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001
Q8013	COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001
Q8015	TRANSISTOR,SILICON KTA1504S_Y_RTK TAAA1504SY
Q8016	COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001
Q8017	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8018	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8019	COMPOUND TRANSISTOR DTA143EKAT146 TPYJA05001
Q8020	COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001
Q8021	COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001
Q8022	COMPOUND TRANSISTOR DTA124EKAT146 TPYJC05001
Q8023	COMPOUND TRANSISTOR DTA124EKAT146 TPYJC05001
Q8025	COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001
Q8027	COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001
Q8029	COMPOUND TRANSISTOR DTC124EKAT146 TNYJC05001
Q8036	COMPOUND TRANSISTOR DTA124EKAT146 TPYJC05001
Q8301	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8302	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8310	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8311	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8314	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8315	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8320	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
Q8321	TRANSISTOR,SILICON KTC3875S_Y_RTK TCAA3875SY
D652	LED LTL-1CHGE-002A 0021E5Q210
D681	LED LTL-1CHAE-002A 0021E3Q030
D701	DIODE,SILICON 1SS133T-77 D1VT001330
D1703	DIODE,SILICON 1SS133T-77 D1VT001330
D1704	DIODE,SILICON 1SS133T-77 D1VT001330
⚠ D1706	DIODE,ZENER MTZJ12B T-77 D97U01201
D1707	DIODE,SILICON 1SS133T-77 D1VT001330
D3001	INFRARED LED LTE-3271T-012A-O 0010E00330
D3007	DIODE,SILICON 1SS133T-77 D1VT001330
D3009	DIODE,SILICON 1SS133T-77 D1VT001330
D8002	DIODE,SILICON 1SS133T-77 D1VT001330
D8003	DIODE,SILICON 1SS133T-77 D1VT001330
D8301	DIODE,SCHOTTKY RB721Q-40 T-77 D1VTB721Q0
D8302	DIODE,SCHOTTKY RB721Q-40 T-77 D1VTB721Q0
D8303	DIODE,SCHOTTKY RB721Q-40 T-77 D1VTB721Q0
D8307	DIODE,SCHOTTKY RB721Q-40 T-77 D1VTB721Q0
D8314	DIODE,SCHOTTKY RB721Q-40 T-77 D1VTB721Q0
COILS AND TRANSFORMERS	
L101	COIL,BIAS OSC 1626009 031626009R
L102	COIL 100 UH 02167F101J
L104	COIL 22 UH 02167F220J
L105	COIL 22 UH 02167F220J
L106	COIL 22 UH 02167F220J
L107	COIL 22 UH 02167F220J
L109	COIL 100 UH 021LA6101J
L301	COIL 22 UH 02167F220J
L651	COIL 100 UH 021LA6101J
L701	COIL 22 UH 02167F220J
L702	COIL 22 UH 02167F220J
L703	COIL 100 UH 021LA6101J
L704	COIL 22 UH 02167F220J
L801	COIL 100 UH 02167F101J
L1701	CORE,FERRITE W5T29X7.5X19 02AHB9A972
L1702	COIL 47 UH 02167F470J
L3003	COIL 12 UH 021LA6120J
L7301	COIL 1 UH 0216S71R0J

7	8
Mark No.	Description Part No.
L7302	COIL 1 UH 0216S71R0J
L7303	COIL 1 UH 0216S71R0J
L7304	COIL 1 UH 0216S71R0J
L7305	COIL 1 UH 0216S71R0J
L7306	COIL 1 UH 0216S71R0J
L7307	COIL 6.8 UH 0216S76R8J
L7308	COIL 6.8 UH 0216S76R8J
L7309	COIL 6.8 UH 0216S76R8J
L8001	COIL 100 UH 021LA6101J
L8002	COIL 100 UH 02167F101J
L8003	COIL 22 UH 02167F220J
L8301	COIL 22 UH 02167F220J
L8302	COIL 100 UH 02167F101J
L8305	COIL 100 UH 02167F101J
L8306	COIL 220 UH 02167F221J
SWITCHES	
SW651	SWITCH,TACT EVQ21505R 0504101T34
SW652	SWITCH,TACT EVQ21505R 0504101T34
SW653	SWITCH,TACT EVQ21505R 0504101T34
SW681	SWITCH,TACT EVQ11L05R 0504R01T38
SW682	SWITCH,TACT EVQ11L05R 0504R01T38
SW683	SWITCH,TACT EVQ11L05R 0504R01T38
SW684	SWITCH,TACT EVQ11L05R 0504R01T38
SW685	SWITCH,TACT EVQ11L05R 0504R01T38
SW686	SWITCH,TACT EVQ11L05R 0504R01T38
SW687	SWITCH,TACT EVQ11L05R 0504R01T38
SW688	SWITCH,TACT EVQ11L05R 0504R01T38
SW3001	SWITCH (LEAF) LSA-1144EAU 0508S11001
RESISTORS	
⚠ R531	R,FUSE 22 OHM 1/4W R65584220
⚠ R533	R,FUSE 2.7 OHM 1/4W R655842R7
⚠ R1750	R,METAL OXIDE 1.5 OHM 2W R3X28A1R5
OTHERS	
B651	CORE,BEADS FCM2012H-102T04 024HC31022
B652	CORE,BEADS FCM2012H-102T04 024HC31022
B653	CORE,BEADS FCM2012H-102T04 024HC31022
B654	CORE,BEADS FCM2012H-102T04 024HC31022
B655	CORE,BEADS FCM2012H-102T04 024HC31022
B4001	CORE,BEADS FCM2012H-102T04 024HC31022
B4002	CORE,BEADS HCB2012K-600T25 024HC36001
B4003	CORE,BEADS HCB2012K-600T25 024HC36001
B4004	CORE,BEADS HCB2012K-600T25 024HC36001
B4005	CORE,BEADS HCB2012K-600T25 024HC36001
B4006	CORE,BEADS FCM2012H-102T04 024HC31022
B4007	CORE,BEADS FCM2012H-102T04 024HC31022
B4008	CORE,BEADS FCM2012H-102T04 024HC31022
B7301	CORE,BEADS FCM2012H-102T04 024HC31022
B7304	CORE,BEADS HCB2012K-600T25 024HC36001
B7305	CORE,BEADS HCB2012K-600T25 024HC36001
B7306	CORE,BEADS HCB2012K-600T25 024HC36001
B7307	CORE,BEADS HCB2012K-600T25 024HC36001
B8001	CORE,BEADS FCM2012H-102T04 024HC31022
B8002	CORE,BEADS FCM2012H-102T04 024HC31022
BT601	BATTERY, MANGAN R03(AB)E_2P_G 1412004008
CD102	CORD,JUMPER 2F061501 0122F061501
⚠ CD501	CORD,SET AC 9619904 120961990
CD502	FLAT CABLE AWM2468 A WG26 16C BLACK 160MM WPL6016038

Mark No.	Description	Part No.
----------	-------------	----------

CD504	CORD,CONNECTOR CU641202	06CU641202
CD651	CORD,CONNECTOR CU252802	06CU252802
CP101	CONNECTOR PCB SIDE TOC-C09X-A1	697290620
CP102	CONNECTOR PCB SIDE IMSA-9604S-06C069J760599	
CP103	WIRE HOLDER B2013H02-2P	067U002019

CP502	WIRE HOLDER B2013H02-16P	067U01601
CP681	CONNECTOR PCB SIDE A2001WR2-5P	069S25063
CD4001	CORD,JUMPER BH040061	12BH040061
CD6002	CABLE CPL02006	06CPL02006
CD6003	CORD,RCA PIN TD-020301-3	06CPBA2003

CD7301	CORD,JUMPER 2H0K1802	122H0K1802
CD7302	CORD,JUMPER 2H0K1802	122H0K1802
CD7303	CORD,JUMPER 2H0I1802	122H0I1802
CD7304	CORD,CONNECTOR CU2A2701	06CU2A2701

CP1701	CONNECTOR PCB SIDE 52147-1610	069R2G058
--------	-------------------------------	-----------

CP1703	CONNECTOR PCB SIDE A2001WV2-10P	069S2A0629
CP3001	CONNECTOR PCB SIDE TMC-J12P-B2	06972C001
CP4001	CONNECTOR PCB SIDE 04_6274_000_800	069S2A0629
CP7304	CONNECTOR PCB SIDE A2001WV2-10P	069S2A0629
CP8301		069JVK0200
	CONNECTOR PCB SIDE IMSA-9615S-20C-PP-A	

CP8302		069JVK0200
	CONNECTOR PCB SIDE IMSA-9615S-20C-PP-A	
CP8303		069JVI0200
	CONNECTOR PCB SIDE IMSA-9615S-18C-PP-A	

DK4001	DECK CD DVR-R07OR	169V00030
ICP501	MICRO FUSE 20N_1000FS	0835C01003

ICP1701	MICRO FUSE 20N_1250FS	0835C01203
M501	FAN MOTOR 2410ML-04W-B10-C47	1519X56L0
NR4001	R,NETWORK 4D03WGGJ0470T5E	110P4470M4
NR4002	R,NETWORK 4D03WGGJ0470T5E	110P4470M4
NR4003	R,NETWORK 4D03WGGJ0470T5E	110P4470M4

NR4004	R,NETWORK 4D03WGGJ0470T5E	110P4470M4
NR4005	R,NETWORK 4D03WGGJ0470T5E	110P4470M4
NR4006	R,NETWORK 4D03WGGJ0470T5E	110P4470M4
NR4007	R,NETWORK 4D03WGGJ0470T5E	110P4470M4
NR4008	R,NETWORK 4D03WGGJ0470T5E	110P4470M4

OS651	REMOTE RECEIVER PIC-37041LO-H	077Q037012
OS8001	OPTICAL DEVICE OFTG038101	07AQ000009
TM601	TRANSMITTER R56-0517	076R0JZ010
TU301	RF UNIT 115-V-H015ARE_G	162300041
V651		096F90R404
	TUBE FLUORSCENT DISPLAY HNV-09SS48	

X101	CRYSTAL HC-49/U	100DT3R528
X3001	CRYSTAL HC-49/U-S	100CT01002
X3002	CRYSTAL DT-26	100DA32R01
X3003	CRYSTAL HC-49/U-S	100CT01403
X4001	CRYSTAL DSO751SV	100DT02712









X8301	CERAMIC OSCILLATOR CSB500E5	1002A0R503
J651	RCA JACK MSP-281V31-A	060J421039
J652	RCA JACK MSP-281V40-B	060J401098
J653	RCA JACK MSP-281V42-B	060J401099
J654	JACK MDC-012V1-A_LF	063D700010

J8001	JACK MDC-012V1-A_LF	063D700009
J8002	RCA JACK MSP-213V2-432_NI_LF	060J431020
J8003	RCA JACK MSP-213V1-432_NI_LF	060J411031
J8004	JACK MDC-070-B_LF	063D700008
J8005	RCA JACK MSP-213V1-732_NI_LF	060J41033

J8006	RCA JACK MSP-213V1-652_NI_LF	060J411032
-------	------------------------------	------------

6. ADJUSTMENT

6.1 SERVICING FIXTURES AND TOOLS

(For 4 heads model) VHS Alignment Tape GGV1183 (VN1S-LI6 ³ H) GGV1184 (VN1S-X6 ³) GGV1185 (VN2E-LI6 ³ H)	GGF1506 Adapter GGF1507 Dial Torque Gauge (10~90 gf•cm) GGF1508 (60~600 gf•cm)	GGF1509 Post Adjustment Screwdriver Part No. SV-TG0-030-000 (small)	GGF1510 X Value Adjustment Screwdriver
			
GGF1511 Master Plane	GGF1512 Reel Disk Height Adjustment Jig	GGV1186 Torque Tape (VHT-063)	
			

Part No.	Parts Name	Remarks
GGV1183	VHS Alignment Tape	Hi-Fi Audio (For 4 heads model)
GGV1184	VHS Alignment Tape	X Value Adjustment (For 4 heads model)
GGV1185	VHS Alignment Tape	EP Monoscope, 6 kHz (For 4 heads model)
GGF1506	Adapter	VSR Torque, Brake Torque (S Reel/T Reel Assy)
GGF1507	Dial Torque Gauge (10~90 gf•cm)	Brake Torque (T Reel Assy)
GGF1508	Dial Torque Gauge (60~600 gf•cm)	VSR Torque, Brake Torque (S Reel)
GGF1509	Post Adjustment Screwdriver	Guide Roller Adjustment
GGF1510	X Value Adjustment Screwdriver	X Value Adjustment
GGF1511	Master Plane	Reel Disk Height Adjustment
GGF1512	Reel Disk Height Adjustment Jig	Reel Disk Height Adjustment
GGV1186	Torque Tape (VHT-063)	Playback Torque, Back Tension Torque During Playback

PREPARATION FOR SERVICING

- While pressing the CH DOWN button on the set for more than 2 seconds, press the POWER button on the set simultaneously at the Power OFF. Although the DVD is connected, the DVD mode cannot be selected.
- Press both CH UP button on the set and the REC button on the set for more than 2 seconds.
(The BOT, EOT, and the Reel Sensor do not work and the VCR deck can be operated without a cassette tape.)
- In case of using a cassette tape, press the EJECT button to insert or eject a cassette tape.
Turn on the power and re-check the cable before checking the trouble points.

When you servicing with connection of DVD, perform the operations above step 2 to step 3.

6.2 ADJUSTMENT ITEMS AND NECESSARY ADJUSTMENT POINTS

■ Adjustment Items

A [Mechanism Part]

1. CONFIRMATION AND ADJUSTMENT

- ① 1-1 CONFIRMATION AND ADJUSTMENT OF REEL DISK HEIGHT
- ② 1-2 CONFIRMATION AND ADJUSTMENT OF TENSION POST POSITION
- ③ 1-3 CONFIRMATION OF PLAYBACK TORQUE AND BACK TENSION TORQUE DURING PLAYBACK
- ④ 1-4 CONFIRMATION OF VSR TORQUE
- ⑤ 1-5 CONFIRMATION OF REEL BRAKE

2. CONFIRMATION AND ADJUSTMENT OF TAPE RUNNING MECHANISM

- ⑥ 2-1 GUIDE ROLLER
- ⑦ 2-2 CONFIRMATION AND ADJUSTMENT OF AUDIO/CONTROL HEAD
- ⑧ 2-3 TAPE RUNNING ADJUSTMENT (X VALUE ADJUSTMENT)
- ⑨ 2-4 CONFIRM HI-FI AUDIO

B

[Electrical Part]

1. BASIC ADJUSTMENT

- ⑩ 1-1 PG SHIFTER
- ⑪ DVD SIDE EEPROM (IC4002) INITIAL SETTING
REPLACING EEPROM (IC4002) IC
- ⑫ REGION SETTING
REPLACING NEW DVD LOADER

C

D

E

F

When

Adjustment Items

Replacing Parts of Mechanism Assy

Replacing
REEL DISK (S REEL, T REEL)



Mechanical point

① ② ③ ④ ⑤

Electrical point

None

Replacing
TENSION BAND
TENSION CONNECT
TENSION ARM ASSY
T BRAKE BAND
T BRAKE SPRING
T BRAKE ARM
IDLLER ASSY
CLUTCH ASSY



Mechanical point

② ③ ④ ⑤

Electrical point

None

Replacing
HEAD (AUDIO CONTROL)
CYLINDER UNIT ASSY



Mechanical point

⑥ ⑦ ⑧ ⑨

Electrical point

⑩

Replacing PCB Assy or Electrical Parts

Replacing
DECK ASSY
VCR MT PCB ASSY



Mechanical point

None

Electrical point

⑩

Replacing
IC4002 (DVD SIDE EEPROM)



Mechanical point

None

Electrical point

⑪

Replacing
DVD LOADER



Mechanical point

None

Electrical point

⑫

6.3 SERVICE MODE LIST

To enter one of the Sub-Service modes, hold a designated key on the unit pressed for a specified period of time while holding another designated key on the unit or on the remote control unit pressed.

Mode of the Unit	Key on the Unit	Key on the Unit	Specified Period (sec)	Description
VCR	FF	CH+	2	For (1) initial setting of the μ -CON on the VCR side, (2) confirmation of initial settings for the Memory IC, and (3) displaying the accumulated time of playback and recording on the screen.
VCR	PLAY	CH+	2	Initialization to the state at shipment Note: Do NOT use this mode during normal servicing. This mode will reset the time setting, channel setting, and the accumulated time of playback/recording.
VCR (Playback)	CH+	CH-	2	For setting tracking to the center value Note: You can enter this mode by holding the ATR key on the remote control unit pressed for 2 seconds.
VCR (Playback)	REC/OTR	DVD/VCR	2	For automatic adjustment of the PG shifter
VCR	CH+	REC/OTR	2	For entering Service mode Entering this mode disables the EOT/BOT/reel sensor and enables the VCR section of the unit to operate even if a tape is not loaded.
VCR	STOP	CH+	2	For entering DVD-Audio-Level/Separation Adjustment mode
DVD	CH-	DVD/VCR	2	For displaying information
VCR	CH-	S-BY/ON	2	For entering Operation-of-Only-VCR-Section mode Note: In this mode, you cannot switch to DVD mode even if connection of the DVD section has been made.

The following Sub-Service modes can be entered by first holding the designated key on the remote control unit pressed then pressing another designated key on the unit.

Mode of the Unit	Key on the Remote Control Unit	Key on the Unit	Specified Period (sec)	Description
DVD (NO DISC)	0	STOP	2	For setting and unlocking the TRAY Lock. This mode functions cyclically.
DVD (NO DISC)	2	STOP	2	F/W Writing mode
DVD	6	STOP	2	For initial setting of μ -CON on the DVD side
DVD (NO DISC)	7	STOP	2	For canceling Parental Lock Note: This mode functions only when a disc is not loaded in DVD mode
DVD (NO DISC)	8	STOP	2	For entering Region-Code Writing mode
DVD (Playback, NO DISC)	9	STOP	2	For displaying Loader Information and error rates

For switching the RF output channels (CH 3/4)

While the unit is off, hold the 3 or 4 key on the remote control unit pressed for at least 3 seconds.

6.5 PREVENTIVE CHECKS AND SERVICE INTERVALS

The following standard table depends on environmental conditions and usage.

Parts replacing time does not mean the life span for individual parts.

Also, long term storage or misuse may cause transformation and aging of rubber parts.

The following list means standard hours, so the checking hours depends on the conditions.

Parts Name	Time 500 hours	1,000 hours	1,500 hours	2,000 hours	2,500 hours	Notes
Audio Control Head	■	■	■	●	●	Clean those parts in contact with the tape.
Full Erase Head (Recorder only)	■	■	■	●	●	
Capstan Belt		●	●	●	●	Clean the rubber, and parts which the rubber touches
Pinch Roller	■	●	●	●	●	
Capstan DD Unit		●	●	●	●	
Loading Motor					●	
Tension Band		●	●	●	●	
T Brake Band		●	●	●	●	
Clutch Assy		●	●	●	●	
Idler Arm Assy		●	●	●	●	
Capstan Shaft	■	■	■	■	■	Replace when rolling becomes abnormal.
Tape Running Guide Post	■	■	■	■	■	
Cylinder Unit	■	●	●	●	●	Clean the Head

■ : Clean

● : Check it and if necessary, replace it

CLEANING


NOTE

After cleaning the heads with isopropyl alcohol, do not run a tape until the heads dry completely. If the heads are not completely dry and alcohol gets on the tape, damage may occur.

1. AUDIO CONTROL HEAD

Clean the Audio Control Head with the cotton stick soaked by alcohol. Clean the full erase head in the same manner.

(Refer to the figure below.)



2. TAPE RUNNING SYSTEM

When cleaning the tape transport system, use the gauze moistened with isopropyl alcohol.

3. CYLINDER


Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol. Hold it to the cylinder head softly.

Turn the cylinder head counterclockwise to clean it (in the direction of the arrow). (Refer to the figure below.)

NOTE

Do not exert force against the cylinder head. Do not move the chamois upward or downward on the head.

Use the chamois one by one.



6.6 MECHANICAL ADJUSTMENTS

1. CONFIRMATION AND ADJUSTMENT



Read the following NOTES before starting work.

- Place an object which weighs between 450g~500g on the Cassette Tape to keep it steady when you want to make the tape run without the Cassette Holder.
(Do not place an object which weighs over 500g.)





1-1: CONFIRMATION AND ADJUSTMENT OF REEL DISK HEIGHT

- Turn on the power and set to the STOP mode.
- Set the master plane (JG022) and reel disk height adjustment jig (JG024A) on the mechanism framework, taking care not to scratch the drum, as shown in Fig. 1-1-A.
- While turning the reel and confirm the following points. Check if the surface "A" of reel disk is lower than the surface "B" of reel disk height adjustment jig (JG024A) and is higher than the surface "C". If it is not passed, place the height adjustment washers and adjust to 10 (+2, -0) mm.
- Adjust the other reel in the same way.



1-2: CONFIRMATION AND ADJUSTMENT OF TENSION POST POSITION

- Set to the PLAY mode.
- Adjust the adjusting section for the Tension Arm position so that the Tension Arm top is within the standard line of Main Chassis.
- While turning the S Reel clockwise, confirm that the edge of the Tension Arm is located in the position described above.



• USING A CASSETTE TYPE TORQUE TAPE (JG100A)

- After confirmation and adjustment of Tension Post position (Refer to item 1-2), load the cassette type torque tape (JG100A) and set to the PLAY mode.
- Confirm that the right meter of the torque tape indicates 50~90gf•cm during playback in SP mode.
- Confirm that the left meter of the torque tape indicates 25~40gf•cm during playback in SP mode.

1-4: CONFIRMATION OF VSR TORQUE

1. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Set to the Picture Search (Rewind) mode. (Refer to Fig.1-4-B)
2. Then, confirm that it indicates 120~180gf•cm.

NOTE



Install the Torque Gauge on the reel disk firmly. Press the REW button to turn the reel disk.

1-5: CONFIRMATION OF REEL BRAKE TORQUE (S Reel Brake) (Refer to Fig. 1-4-B)

1. Once set to the Fast Forward mode then set to the Stop mode. While, unplug the AC cord when the Pinch Roller Block is on the position of Fig. 1-4-A.
2. Move the Idler Assy from the S Reel.
3. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Turn the Torque Gauge (JG002F) clockwise.
4. Then, confirm that it indicates 60~100gf•cm.

(T Reel Brake) (Refer to Fig. 1-4-B)

1. Once set to the Fast Forward mode then set to the Stop mode. While, unplug the AC cord when the Pinch Roller Block is on the position of Fig. 1-4-A.
2. Move the Idler Assy from the T Reel.
3. Install the Torque Gauge (JG002E) and Adapter (JG002B) on the T reel. Turn the Torque Gauge (JG002E) counterclockwise.
4. Then, confirm that it indicates 30~50gf•cm.



NOTE

If the torque is out of the range, replace the following parts.

Check Item	Replacement Part
1-4	Idler Assy / Clutch Assy
1-5	S Reel side : S Reel/ Tension Band/Tension Connect/Tension Arm Assy T Reel side : T Reel/ Brake Band/T Brake Spring /T Brake Arm

2. CONFIRMATION AND ADJUSTMENT OF TAPE RUNNING MECHANISM



Tape Running Mechanism is adjusted precisely at the factory. Adjustment is not necessary as usual. When you replace the parts of the tape running mechanism because of long term usage or failure, the confirmation and adjustment are necessary.

2-1: GUIDE ROLLER

1. Playback the VHS Alignment Tape (JG001 or JG001B). (Refer to **SERVICING FIXTURE AND TOOLS**)
2. Connect CH-1 of the oscilloscope to TP101 (Envelope) and CH-2 to TP3002 (SW Pulse).
3. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
4. Trigger with SW Pulse and observe the envelope. (Refer to Fig. 2-1-A)
5. When observing the envelope, adjust the Adjusting Driver (JG005) slightly until the envelope will be flat. Even if you press the Tracking Button, adjust so that flatness is not moved so much.
6. Adjust so that the A : B ratio is better than 3 : 2 as shown in Fig. 2-1-B, even if you press the Tracking Button to move the envelope (The envelope waveform will begin to decrease when you press the Tracking Button).
7. Adjust the PG shifter during playback. (Refer to the **ELECTRICAL ADJUSTMENTS**)

NOTE




After adjustment, confirm and adjust A/C head. (Refer to item 2-2)



2-2: CONFIRMATION AND ADJUSTMENT OF AUDIO/CONTROL HEAD


When the Tape Running Mechanism does not work well, adjust the following items.

1. Playback the VHS Alignment Tape (**JG001** or **JG001B**).
(Refer to **SERVICING FIXTURE AND TOOLS**)
2. Confirm that the reflected picture of stamp mark is appeared on the tape prior to P4 Post as shown in **Fig. 2-2-A**.
 - a) When the reflected picture is distorted, turn the screw ① clockwise until the distortion is disappeared.
 - b) When the reflected picture is not distorted, turn the screw ① counterclockwise until little distortion is appeared, then adjust the a).
3. Turn the screw ② to set the audio level to maximum.
4. Confirm that the bottom of the Audio/ Control Head and the bottom of the tape is shown in **Fig. 2-2-C**.
 - c) When the height is not correct, turn the screw ③ to adjust the height. Then, adjust the 1~3 again.



2-3: TAPE RUNNING ADJUSTMENT (X VALUE ADJUSTMENT)


1. Confirm and adjust the height of the Reel Disk.
(Refer to item 1-1)
2. Confirm and adjust the position of the Tension Post.
(Refer to item 1-2)
3. Adjust the Guide Roller. (Refer to item 2-1)
4. Confirm and adjust the Audio/Control Head.
(Refer to item 2-2)
5. Connect CH-1 of the oscilloscope to **TP3002**, CH-2 to **TP101** and CH-3 to **HOT side of Audio Out Jack**.
6. Playback the VHS Alignment Tape (**JG001S** or **JG001T**).
(Refer to **SERVICING FIXTURE AND TOOLS**)
7. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
8. Set the X Value adjustment driver (**JG153**) to the ④ of **Fig. 2-2-B**. Adjust X value so that the envelope waveform output becomes maximum. Check if the relation between Audio and Envelope waveform becomes (1) or (2) of **Fig. 2-3**.
9. Playback the VHS Alignment Tape (**JG195**).
(Refer to **SERVICING FIXTURE AND TOOLS**)
10. Check if the picture is played back correctly.



2-4: CONFIRM HI-FI AUDIO (Hi-Fi model only)

1. Connect CH-1 of the oscilloscope to **TP101** and CH-2 to the **Hi-Fi Audio Out Jack**.
2. Playback the VHS Alignment Tape (**JG001P** or **JG001Q**).
(Refer to **SERVICING FIXTURE AND TOOLS**)
3. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
4. Press the Tracking Up button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
5. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
6. Press the Tracking Down button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
7. If the difference are more than 3 steps, set the X Value adjustment driver (**JG153**) to ④ of **Fig. 2-2-B**. Change the X Value and adjust it so that the value becomes within 2 steps.

3. MECHANISM ADJUSTMENT PARTS LOCATION GUIDE



- | | |
|-----------------------------------|--|
| 1. Tension Connect | 6. P4 Post |
| 2. Tension Arm | 7. T Brake Spring |
| 3. Guide Roller | 8. T Reel |
| 4. Audio/Control Head | 9. S Reel |
| 5. X value adjustment driver hole | 10. Adjusting section for the Tension Arm position |

6.7 ELECTRICAL ADJUSTMENTS

Read and perform this adjustment when repairing the circuits or replacing electrical parts or PCB assemblies.



1. BASIC ADJUSTMENT

CAUTION

When you exchange IC and Transistor for a heat sink, apply the silicon grease (**YG6260M**) on the contact section of the heat sink. Before applying new silicon grease, remove all the old silicon grease. (Old grease may cause damages to the IC and Transistor.)

1-1: PG SHIFTER

CONDITIONS

MODE-PLAYBACK

Input Signal-Alignment Tape (**JG001B**)

INSTRUCTIONS

1. Connect CH-1 on the oscilloscope to **TP3002** and CH-2 to **J8005**.
2. Playback the alignment tape. (**JG001B**)
3. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
4. Press both CH UP button on the set and the STOP button on the set for more than 2 seconds.




Fig. 1-1-A




Fig. 1-1-B

2. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE (WIRING CONNECTION)

A


B

C

D

E

F



6.8 WHEN REPLACING NEW DVD LOADER

NOTE:

If a service repair is undertaken where it has been required to change the New DVD Loader, Region setting is needed. If the Region setting does not performed, only the Region Free disc can be played. Region setting can only be done once. So, take notice very carefully.

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the DVD mode.
3. Press both Channel button (8) on the remote control and the STOP button on the set for more than 2 seconds. Tray will open.
4. Place your Region setting disc (Region 1) on the tray and close. Writing will start.
5. After the writing, the writing Region No. will appear on the TV Monitor.

Perform the initializing of shipping (*)

6. Press both CH UP button on the set and the PLAY button on the set for more than 2 seconds.
7. After the finishing of the initializing of shipping, the unit will turn off automatically.

* : When initializing to shipping data, the VCR operating time record is cleared.

Check for the Region No.

8. Turn on the POWER, and set to the DVD mode.
9. Press both CH DOWN button on the set and the DVD/VCR button on the set for more than 2 seconds. Information screen will be displayed on the TV Monitor. (Refer to Fig. 1)
10. If the writing Region No. is appeared, the Region setting is completed.
11. Turn off the power.

	Vaddis	Timer
Ver.	RXD47280-P	0E0142B610A
C. Sum	010901B3	13E4
Accum	000000	0000
DVD	PIONEER DVD-RW DVR-R07RZ	
	1.03	Region-1

Region No.

Fig. 1

6.9 WHEN REPLACING EEPROM (MEMORY) IC

If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to TABLE 1.

NOTE: After the DATA change, if the ENTER button is not pressed at the DATA selection mode and the power is turned off, the DATA change does not performed.

After the DATA change, press the ENTER button by all means and set to the ADDRESS selection mode, then turn off the power.

DVD side EEPROM (IC4002) initial setting

NOTE: INI 3FF data can not be set.

The datas for the address excepting from 3A0 to 3FF are displayed "ERR". This unit is not defective.

* Do not change other address data.

INIT	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+A	+B	+C	+D	+E	+F
3A0	01	01	00	01	02	00	00	00	02	07	01	02	01	02	02	00
3B0	02	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
3C0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
3D0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
3E0	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00
3F0	00	00	00	00	00	00	00	00	00	00	00	00	00	01	09*	---

* RT500=09
RT300=11

Table 1

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the DVD mode.
3. Press both Channel button (6) on the remote control and the STOP button on the set for more than 2 seconds. ADDRESS and DATA will appear on TV Monitor as Fig 1 and the ADDRESS is now selected.




Fig. 1

4. Input the ADDRESS by using Channel +/- button or the following buttons below.
Numbers are 10 keys from 0 to 9, Alphabets are
A: VCR EJECT, B: DVD OPEN/CLOSE, C: DVD/VCR, D: TIMER REC, E: INPUT SELECT, F: DISPLAY/CALL.
5. Press ENTER to select DATA.
6. Again, step through the DATA using Channel + or - button until required DATA value has been selected.
7. Pressing ENTER will take you back to ADDRESS for further selection if necessary.
8. Repeat steps 4 to 7 until all data has been checked.
9. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input.

After the data input, set to the initializing of shipping (*).

10. Turn on the POWER, and set to the DVD mode.
11. Press both CH UP button on the set and the PLAY button on the set for more than 2 seconds.
12. After the finishing of the initializing of shipping, the unit will turn off automatically.
The unit will now have the correct DATA for the new MEMORY IC.

* : When initializing to shipping data, the VCR operating time record is cleared.

7. GENERAL INFORMATION

7.1 RE-WRITE FOR DVD FIRMWARE

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the DVD mode.
3. Confirm that the "No Disc" will be appeared on the screen.
A disc is already inserted, eject the disc and power it off and on again.
4. Open the DVD tray.
5. Press both Channel button (2) on the remote control and the STOP button on the set for more than 2 seconds.
6. Press OPEN/CLOSE button on the set to check if all the keys on the unit do not function.
NOTE: To check if DVD Write mode is set.
7. Place the Up-Date Disc and close the tray by hand. (Refer to SERVICING FIXTURE AND TOOLS)
8. Automatic read will start and "SDRAM writing" will be displayed on the screen.
9. Approx. 7 seconds later, the tray will open automatically. Remove the Up-Date Disc.
The display will change to "FLASH writing".
10. Then, Approx. 2 minutes 30 seconds later, the above indication will disappear and the tray will close automatically.
When the "Please Reboot" appears on the screen, the writing will be finished.
NOTE: Do not turn off the unit on the way or push the tray by hand to close it.
Up-Date error will happen and can not be done with the Up-Date of Up-Date Disc.
11. Unplug the AC cord, then plug it in.

After the write, set to the initializing of shipping (*).

12. Turn on the POWER, and set to the DVD mode.
13. Press both CH UP button on the set and the PLAY button on the set for more than 2 seconds.
14. After the finishing of the initializing of shipping, the unit will turn off automatically.

* : When initializing to shipping data, the VCR operating time record is cleared.

CHECK FOR THE FIRMWARE VERSION

15. Turn on the POWER, and set to the DVD mode.
16. Press both CH DOWN button on the set and the DVD/VCR button on the set for more than 2 seconds.
Information screen will be displayed on the TV Monitor. **(Refer to Fig. 1)**
17. When the changed version displays, the Re-write will be completed.
18. Turn off the power

Firmware version

	Vaddis	Timer
Ver.	RXD47280-P	0E0142B610A
C. Sum	010901B3	13E4
Accum	000000	0000
DVD	PIONEER DVD-RW	DVR-R07RZ
	1.03	Region-1

Fig. 1


■1■2■3■4■

7.2 MEASUREMENT OF ERROR RATE

[Measurement Steps]

- A
- 1) Load the disc that you want to measure the error rate of.
- 2) During playback, press "9" on the remote control and "STOP" on the main unit at the same time to measure the error rate for that part of the disc.
- 3) After the error rate has been measures, it is displayed on the screen. (This display is not updated.)

B



Error rate value =
$$\frac{\text{numerator of PI}}{\text{denominator of PI}}$$

(*) : decimal digit

Fig. 1

-
- 4) To clear the error rate display from the screen, press "9" on the remote control and "STOP" on the main unit at the same time again.
When clearing this display, the error rate measurement is not executed.

C

Table 1: List of Reference Value

Disc Type	Recording Mode	Reference Value
DVD-VIDEO		8.0×10^{-4}
DVD-R	Video mode	1.0×10^{-3}
DVD-RW	Video mode	1.0×10^{-3}


D

E

F

7.3 POWER ON SEQUENCE

Power on Sequence



7.4 DISC REMOVAL METHOD

1. Insert a fine rod (wire etc.) into the hole of the Front Cabinet as shown by the arrow. **(Refer to Fig. 1)**
The Tray is opened.
2. Draw the Tray.




Fig. 1

7.5 TAPE REMOVAL METHOD AT NO POWER SUPPLY

1. Remove the Top Cabinet, Front Cabinet and DVD Block. **(Refer to item 1 of the DISASSEMBLY INSTRUCTIONS.)**
2. Remove one screw of the Loading Motor from the insert hole for screw driver and remove the Loading Motor.
3. Rotate the Pinch Roller Cam in the direction of the arrow by hand to slacken the Video Tape.
(Refer to Fig. 2)
4. Rotate the Clutch Ass'y either of the derections to wind the Video Tape in the Cassette Case.
5. Repeat the above step 3~4. Then take out the Video Cassette from the Deck Chassis. Be careful not to scratch on the tape.




Fig. 1




Fig. 2

7.6 PARENTAL CONTROL-RATING LEVEL

4 DIGIT PASSWORD CANCELLATION

If the stored 4 digit password in the Rating Level menu needs to be cancelled, please follow the steps below.

1. Turn Unit ON.
2. Press and hold the '7' key on the remote control unit.
3. Simultaneously press and hold the 'STOP' key on the front panel.
4. Hold both keys for more than 2 seconds.
5. The On Screen Display message 'PASSWORD UNLOCK' will appear.
6. The 4 digit password has now been cleared

NB: No indications on the screen when the Parental Lock is setting.

7.7 TRAY LOCK

Tray cannot be opened by setting the Tray Lock, please follow the steps below.

1. Turn Unit ON.
2. Press and hold the '0' key on the remote control unit.
3. Simultaneously press and hold the 'STOP' key on the front panel.
4. Hold both keys for more than 2 seconds.
5. Press the OPEN/CLOSE key on the front panel to check the Tray Lock setting.

NB: No indications on the screen when the Tray Lock is setting.


To unlock the Tray Lock, follow the steps above again.

7.8 DISASSEMBLY

1. REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS


1-1: TOP CABINET AND FRONT CABINET (Refer to Fig. 1-1)

1. Remove the 5 screws ①.
2. Remove the Top Cabinet in the direction of arrow (A).
3. Disconnect the following connector: (CP681).
4. Unlock the 10 supports ②.
5. Remove the Front Cabinet in the direction of arrow (B).
6. Remove the 3 screws ③.
7. Remove the Operation PCB in the direction of arrow (C).




1-2: FLAP (Refer to Fig. 1-2)

1. Open Flap to 90° and flex in direction of arrow (A), at the same time slide in direction of arrow (B).
2. Then lift in direction of arrow (C).



1-3: DECK CD AND DVD/HD MPEG PCB (Refer to Fig. 1-3)

1. Remove the 2 screws ①.
2. Remove the Deck Shield Assy in the direction of arrow (A).
3. Remove the 6 screws ②.
4. Disconnect the following connectors: (CP504, CP1703, CP8301, CP8302, CP8303).
5. Remove the Deck CD Block in the direction of arrow (B).
6. Remove the 4 screws ③.
7. Remove the MPEG Shield in the direction of arrow (C).
8. Disconnect the following connector: (CP4001).
9. Remove the DVD/HD MPEG PCB in the direction of arrow (D).
10. Remove the 2 screws ④.
11. Remove the DVD Angle (L) in the direction of arrow (E).
12. Remove the 2 screws ⑤.
13. Remove the DVD Angle (R) in the direction of arrow (F).



1-4: POWER PCB (Refer to Fig. 1-4)

1. Remove the 2 screws ①.
2. Disconnect the following connector: (CP506).
3. Remove the Fan Motor in the direction of arrow (A).
4. Remove the 3 screws ②.
5. Disconnect the following connector: (CP1701).
6. Remove the Power PCB in the direction of arrow (B).




Fig. 1-4

1-6: VCR PCB (Refer to Fig. 1-6)

1. Remove the screw ①.
2. Remove the screw ②.
3. Remove the 7 screws ③.
4. Remove the Jack Shield.
5. Remove the VCR PCB in the direction of arrow.




Fig. 1-6

1-5: VCR DECK (Refer to Fig. 1-5)

NOTE:

Do not remove the cable at the FE Head section. The FE Head may be damaged if you remove the cable by force.

1. Unlock the 2 supports ① and remove the Top Holder.
2. Remove the screw ②.
3. Remove the FE Head.
4. Move the Cassette Holder Assy to the back side.
5. Remove the 3 screws ③.
6. Disconnect the following connectors: (CP101, CP102, CP3001).
7. Remove the AC Head Cover and VCR Deck in the direction of arrow.




Fig. 1-5


2. REMOVAL OF VCR DECK PARTS

2-1: TOP BRACKET (Refer to Fig. 2-1)

1. Extend the 2 supports ①.
2. Slide the 2 supports ② and remove the Top Bracket.


NOTE

1. After the installation of the Top Bracket, bend the support ① so that the Top Bracket is fixed.




NOTE:

1. In case of the Locker R installation, check if the one position of Fig.2-3-B are correctly locked.
2. When you install the Cassette Side R, be sure to move the Locker R after installing.




2-2: CASSETTE HOLDER ASSY (Refer to Fig. 2-2)

1. Move the Cassette Holder Assy to the front side.
2. Push the Locker R to remove the Cassette Side R.
3. Remove the Cassette Side L.




2-4: LINK UNIT (Refer to Fig. 2-4)

1. Set the Link Unit to the Eject position.
2. Unlock the support ①.
3. Remove the (A) side of the Link Unit first, then remove the (B) side.




2-3: CASSETTE SIDE L/R (Refer to Fig. 2-3-A)

1. Remove the Locker Spring.
2. Unlock the 4 supports ① and then remove the Cassette Side L/R.
3. Unlock the support ② and then remove the Locker R.




2-5: LINK LEVER/FLAP LEVER (Refer to Fig. 2-5)

1. Extend the support ①.
2. Remove the Link Lever.
3. Remove the Flap Lever.






2-6: LOADING MOTOR/WORM (Refer to Fig. 2-6-A)

1. Remove the screw ①.
2. Remove the Loading Motor.
3. Remove the Worm.





NOTE:

1. In case of the Worm installation, check if the value of the Fig. 2-6-B is correct.
2. In case of the Loading Motor installation, hook the wire on the Cassette Opener as shown Fig. 2-6-C.
3. When installing the wires between Capstan DD Unit and Loading Motor, connect them correctly as shown Fig. 2-6-D.






2-7: TENSION ASSY (Refer to Fig. 2-7-B)

1. Turn the Pinch Roller Cam clockwise so that the Tension Holder hook is set to the position of Fig. 2-7-A to move the Tension Arm Assy.
2. Remove the Tension Spring.
3. Unlock the 2 supports ① and remove the Tension Band.
4. Unlock the support ② and remove the Tension Arm Assy.
5. Unlock the support ③ and remove the Tension Connect.
6. Float the hook ④ and turn it clockwise then remove the Tension Holder.



NOTE:

1. In case of the Tension Band installation, note the direction of the installation. (Refer to Fig. 2-7-C)
2. In case of the Tension Band installation, install correctly as Fig. 2-7-D.
3. In case of the Tension Connect installation, install as the circled section of Fig. 2-7-E.



2-8: T BRAKE ARM/T BRAKE BAND

(Refer to Fig. 2-8-A)

1. Remove the T Brake Spring.
2. Turn the T Brake Arm clockwise and bend the hook section to remove it.
3. Unlock the 2 supports ① and remove the T Brake Band.




Fig. 2-8-A

NOTE:

1. In case of the T Brake Band installation, install correctly as Fig. 2-8-B.




Fig. 2-8-B

2-9: S REEL/T REEL/IDLER ARM ASS'Y/IDLER GEAR (Refer to Fig. 2-9-A)

1. Remove the S Reel and T Reel.
2. Remove the 2 Polyslider Washers ①.
3. Remove the Idler Arm Ass'y and Idler Gear.

NOTE:

1. Take care not to damage the gears of the S Reel and T Reel.
2. The Polyslider Washer may be remained on the back of the reel.
3. Take care not to damage the shaft.
4. Do not touch the section "A" of S Reel and T Reel. (Use gloves.) (Refer to Fig. 2-9-A) Do not adhere the stains on it.
5. When you install the reel, clean the shaft and grease it (FG-84M). (If you do not grease, noise may be heard in FF/REW mode.)
6. After installing the reel, adjust the height of the reel. (Refer to MECHANICAL ADJUSTMENT)




Fig. 2-9-A

NOTE:

1. In case of the S Reel and T Reel installation, check if the correct parts are installed. (Refer to Fig. 2-9-B)
2. In case of the Idler Arm Ass'y installation, install correctly as Fig. 2-9-C. And also set it so that the section "B" of Fig. 2-9-A is placed under the Main Chassis tab.




Fig. 2-9-B





Fig. 2-9-C


2-10: CASSETTE OPENER/PINCH ROLLER BLOCK/P5 ARM ASSY (Refer to Fig. 2-10-A)

1. Unlock the support ① and remove the Cassette Opener.
2. Remove the Pinch Roller Block and P5 Arm Assy.



NOTE:

1. Do not touch the Pinch Roller. (Use gloves.)
2. In case of the Pinch Roller Block and the Pinch Roller Cam installation, install correctly as Fig. 2-10-B.





2-11: A/C HEAD (Refer to Fig. 2-11-A)

1. Remove the screw ①.
2. Remove the A/C Head Base.
3. Remove the 3 screws ②.
4. Remove the A/C Head and A/C Head Spring.


NOTE:

1. Do not touch the A/C Head. (Use gloves.)
2. When you install the A/C Head Spring, install as shown in Fig. 2-11-B.
3. When you install the A/C Head, tighten the screw (1) first, then tighten the screw (2), finally tighten the screw (3).



2-12: FE HEAD (RECORDER ONLY) (Refer to Fig. 2-12)

1. Remove the screw ①.
2. Remove the FE Head.




2-13: AHC ASSY/CYLINDER UNIT ASSY (Refer to Fig. 2-13)

1. Unlock the support ① and remove the AHC Assy.
2. Disconnect the following connector: (CD2001)
3. Remove the 3 screws ②.
4. Remove the Cylinder Unit Assy.


NOTE:

1. When you install the Cylinder Unit Assy, tighten the screws from (1) to (3) in order while pulling the Assy toward the left front direction.




2-14: CAPSTAN DD UNIT (Refer to Fig. 2-14)

1. Remove the Capstan Belt.
2. Remove the screw ①.
3. Remove the Capstan Holder.
4. Remove the 3 screws ②.
5. Remove the Capstan DD Unit.




2-15: MAIN CAM/PINCH ROLLER CAM/JOINT GEAR (Refer to Fig. 2-15-A)

1. Remove the E-Ring ①, then remove the Main Cam.
2. Remove the E-Ring ②, then remove the Pinch Roller Cam and Joint Gear.




NOTE:

1. In case of the Pinch Roller Cam and Main Cam installation, install them as the circled section of Fig. 2-15-B so that the each markers are met.
(Refer to Fig. 2-15-B)




2-16: LOADING GEAR S/T UNIT (Refer to Fig. 2-16-A)

1. Remove the E-Ring ① and remove the Main Loading Gear.
2. Remove the Main Rod, Tension Lever, Loading Arm S Unit and Loading Arm T Unit.




NOTE:

1. When you install the Loading Arm S Unit, Loading Arm T Unit and Main Loading Gear, align each marker.
(Refer to Fig. 2-16-B)




2-17: CLUTCH ASSY/RING SPRING/CLUTCH LEVER/CLUTCH GEAR (Refer to Fig. 2-17-A)

1. Remove the Polyslider Washer ①.
2. Remove the Clutch Assy and Ring Spring.
3. Remove the Clutch Lever.
4. Remove the Coupling Gear, Coupling Spring and Clutch Gear.




NOTE:

1. In case of the Clutch Assy installation, install it with inserting the spring of the Clutch Assy into the dent of the Coupling Gear. (Refer to Fig. 2-17-B)





2-18: CASSETTE GUIDE POST/INCLINED BASE S/T UNIT/P4 CAP/LED REFLECTOR (Refer to Fig. 2-18-A)

1. Remove the P4 Cap.
2. Unlock the support ① and remove the Cassette Guide Post.
3. Remove the Inclined Base S/T Unit.
4. Remove the screw ②.
5. Remove the LED Reflector.



NOTE:

1. Do not touch the roller of Guide Roller.
2. In case of the P4 Cap installation, install it with parallel for "A" and "B" of Fig. 2-18-B.
3. In case of the Cassette Guide Post installation, install correctly as the circled section of Fig. 2-18-C.



7.9 CAUTIONS ON DIASSEMBLING AND ASSEMBLING

Screw List

Parts Name	Num.	Used part	Parts Code
SCREW, TAP TITE(B) WH7 3*10 CH	1	HEAT SINK	8109I30A0U
SCREW, TAP TITE(P) WH10 M2.6*8 CH	1	SPRING of DVD FLAP	8110E2680U
SCREW, TAP TITE(P) BIND 2.6*8 CH	3	OPERATION PCB	8110022680U
SCREW, BIND 3*6 CH	4	ANGLE DVD + LOADER	810223060U
SCREW, TAP TITE(S) BIND 3*4 CH	1	TUNER	810723040U
SCREW, TAP TITE(B)R PAN 3*29 CH	3	VCR DECK	8109130B9U
SCREW, TAP TITE(B) R BIND 3*7 CH	13	VCR PCB 1 MPEG PCB 4 ANGLE DVD + BOTTOM 6 ANGLE DVD + SHIELD 2	810923070U
SCREW, TAP TITE(B) BIND 3*8 CH	12	POWER PCB 3 3PIN JACK 4 FAN 2 S-VIDEO 2 OPTICAL JACK 1	810923080U
SCREW, TAP TITE(B) BIND(3D) 3*6 NI	5	CABINET TOP	8109K30601

CORD CONNECTOR, CORD JUMPER List

Parts Name	Used part	REF NO.	Parts Code
CORD CONNECTOR CU2A2701 L=270MM P=2.0MM 10PIN	VCR⇔MPEG 10 wires	CD7304	06CU2A2701
CORD CONNECTOR CU2252802 L=285MM P=2.0MM 5PIN	VCR⇔OPERATION	CD651	06CU252802
CORD CONNECTOR CU641202 4PIN L=120MM P=2.5MM	DVD DECK⇔POWER for DECK Power	CD504	06CU641202
CORD JUMPER BH040061 L=60MM P=0.5MM H=8MM 40PIN	DVD DECK⇔MPEG	CD4001	12BH040061
CORD JUMPER 2F061501 6PIN FFC L=150MM	VCR⇔AC HEAD	CD102	122F061501
CORD JUMPER 2H011802 18PIN L=180MM P=1.0MM	MPEG⇔VCR	CD7303	122H011802
CORD JUMPER 2H0K1802 20PIN L=180MM P=1.0MM FFC	MPEG⇔VCR	CD7301	122H0K1802
CORD JUMPER 2H0K1802 20PIN L=180MM P=1.0MM FFC	MPEG⇔VCR	CD7302	122H0K1802

CAUTION


- When reattaching the Front Cabinet, attach the cabinet pressing the Flap of VCR side toward inside.
- When reattaching the POWER PCB Assy to the Plate bottom, tighten the two screws for the round holes first then tighten the screws for the slotted holes.
- When reattaching the Angle DVD to the DVD deck, tighten the screws for the round holes situated on the rear side first.
- Insert each flexible cable straight, to avoid loose connection.
- Be sure to pass the binder through the ferrite core that is attached to the CD7304 (10 wires that connect between MPEG and VCR) and secure and fix both the ferrite core and the CD7304 using the binder. If only the wires are secured but the ferrite core is not, the ferrite core may have movement and become damaged.
- When attaching the ferrite core to the CD7304, pass the wires through it twice (one wind around it). Incorrect attachment of the ferrite core may compromise its effects of reducing spurious radiation.

Ferrite Core





■ CAUTION (Continued)

7. Be sure to reattach the Cover AC Head, which is for preventing noise from invading normal audio signals.



8. Be sure to reattach the Shield 3 Pin to the front jack and the Shield Compo to the rear jack of the VCR MT PCB Assy. Those are for preventing electrostatics.

9. Be sure to reattach the Shield 3 Pin so that part of it protrudes from the Plate bottom. Be careful that the Shield 3 Pin is not embedded between the Plate bottom and the circuit board.








7.10 KEY TO ABBREVIATIONS

A	A/C	: Audio/Control	L	LP	: Long Play		
	ACC	: Automatic Color Control		L.P.F	: Low Pass Filter		
	AE	: Audio Erase		LUMI.	: Luminance		
	AFC	: Automatic Frequency Control		M	M	: Motor	
	AFT	: Automatic Fine Tuning			MAX	: Maximum	
	AFT DET	: Automatic Fine Tuning Detect			MINI	: Minimum	
	AGC	: Automatic Gain Control			MIX	: Mixer, mixing	
	AMP	: Amplifier			MM	: Monostable Multivibrator	
	ANT	: Antenna			MOD	: Modulator, Modulation	
	A.PB	: Audio Playback			MPX	: Multiplexer, Multiplex	
	APC	: Automatic Phase Control			MS SW	: Mecha State Switch	
	ASSY	: Assembly		N	NC	: Non Connection	
AT	: All Time	NR	: Noise Reduction				
AUTO	: Automatic	O	OSC	: Oscillator			
A/V	: Audio/Video		OPE	: Operation			
B	BGP	: Burst Gate Pulse	P	PB	: Playback		
	BOT	: Beginning of Tape		PB CTL	: Playback Control		
	BPF	: Bandpass Filter		PB-C	: Playback-Chrominance		
	BRAKE SOL	: Brake Solenoid		PB-Y	: Playback-Luminance		
	BUFF	: Buffer		PCB	: Printed Circuit Board		
	B/W	: Black and White		P. CON	: Power Control		
C	C	: Capacitance, Collector	R	PD	: Phase Detector		
	CASE	: Cassette		PG	: Pulse Generator		
	CAP	: Capstan		P-P	: Peak-to Peak		
	CARR	: Carrier		S	R	: Right	
	CH	: Channel			REC	: Recording	
	CLK	: Clock			REC-C	: Recording-Chrominance	
	CLOCK (SY-SE)	: Clock (Syscon to Servo)			REC-Y	: Recording-Luminance	
	COMB	: Combination, Comb Filter			REEL BRK	: Reel Brake	
	CONV	: Converter			REEL S	: Reel Sensor	
	CPM	: Capstan Motor			REF	: Reference	
	CTL	: Control			REG	: Regulated, Regulator	
	CYL	: Cylinder			REW	: Rewind	
CYL-M	: Cylinder-Motor	REV, RVS	: Reverse				
CYL SENS	: Cylinder-Sensor	RF	: Radio Frequency				
D	DATA (SY-CE)	: Data (Syscon to Servo)	S		RMC	: Remote Control	
	dB	: Decibel			RY	: Relay	
	DC	: Direct Current		T	S. CLK	: Serial Clock	
	DD Unit	: Direct Drive Motor Unit			S. COM	: Sensor Common	
	DEMODO	: Demodulator			S. DATA	: Serial Data	
	DET	: Detector			SEG	: Segment	
	DEV	: Deviation			SEL	: Select, Selector	
	E	E			: Emitter	SENS	: Sensor
		EF			: Emitter Follower	SER	: Search Mode
		EMPH			: Emphasis	SI	: Serial Input
		ENC			: Encoder	SIF	: Sound Intermediate Frequency
		ENV			: Envelope	SO	: Serial Output
EOT		: End of Tape	SOL		: Solenoid		
F	EQ	: Equalizer	SP		: Standard Play		
	EXT	: External	STB		: Serial Strobe		
	G	F	: Fuse		SW	: Switch	
		FBC	: Feed Back Clamp		SYNC	: Synchronization	
		FE	: Full Erase		SYNC SEP	: Sync Separator, Separation	
		FF	: Fast Forward, Flipflop	U	UNREG	: Unregulated	
FG		: Frequency Generator	V		V	: Volt	
FL SW		: Front Loading Switch			VCO	: Voltage Controlled Oscillator	
FM		: Frequency Modulation			VIF	: Video Intermediate Frequency	
FSC		: Frequency Sub Carrier		VP	: Vertical Pulse, Voltage Display		
FWD	: Forward	V.PB		: Video Playback			
H	GEN	: Generator	VR	: Variable Resistor			
	GND	: Ground	V.REC	: Video Recording			
	I	H.P.F	: High Pass Filter	VSF	: Visual Search Fast Forward		
		H.SW	: Head Switch	VSR	: Visual Search Rewind		
		Hz	: Hertz	VSS	: Voltage Super Source		
		K	IC	: Integrated Circuit	V-SYNC	: Vertical-Synchronization	
IF	: Intermediate Frequency		VT	: Voltage Tuning			
IND	: Indicator		X	X'TAL	: Crystal		
INV	: Inverter			Y	Y/C	: Luminance/Chrominance	
L	KIL	: Killer			L	L	: Left
	LED	: Light Emitting Diode				LED	: Light Emitting Diode
	LIMIT AMP	: Limiter Amplifier	LIMIT AMP			: Limiter Amplifier	
	LM, LDM	: Loading Motor	LM, LDM	: Loading Motor			

Discs which can be played back

In this unit, use only discs that meet the standard, such as those bearing the below logo marks on the disc label surface. If you use a non-standard disc, we cannot guarantee playback. Even if such a disc can be played back, we cannot guarantee the image or sound quality. The DVD logo is a registered trademark.

Media type	Logo mark
DVD-Video	
DVD-RW Ver.1.0 Ver.1.1 Ver.1.2 Ver.1.1CPRM support Ver.1.2CPRM support	
DVD-R Ver.2.0 (Ver.2.0/4x/8x)	
Audio CD*	
CD-R/CD-RW	

* This unit is designed to playback music Compact Discs (CD) that conform to the CD standard. CDs that contain (copy-restriction) signals to protect copyrights cannot be played back.

Older models of DVD recorders and DVD writers may reject DVD-RW Ver.1.2 / 4x discs. If you want to share DVD-RW discs between this recorder and an older recorder/writer, we recommend using Ver.1.1 discs.


Region management information

This unit is designed and manufactured to support the region management information that is recorded on a DVD disc. If the region number written on the DVD disc does not correspond to the region number of this unit, this unit cannot play that disc.

- The region number of this unit is “1”.
- The unit will play DVD-Video discs marked with labels containing “1” or “ALL”.

Example:  

Operating DVD-Video

- Some operations of DVD-Video may be prohibited by the manufacturer, or some operation methods or functions of the DVD-Video may be different from the description in this manual.
- If you attempt an operation that is prohibited by either the disc or the unit, a “ ” mark will appear on the TV monitor. For operations prohibited by the disc, see the information that came with the disc.
- When the menu screen or the operation guide appears during disc playback, follow the displayed information.

Discs which cannot be played back

The discs listed below cannot be played back in general. Even if one of these can be played back, it may not be played back correctly. If a disc is played back by mistake, extensively loud sounds may blow the speakers or may damage the hearing of those in hearing range.

Do not playback the discs listed below
 CDG, Photo-CD, CD-ROM, CD-TEXT,CD-EXTRA, VCD, SVCD, SACD, PD, CDV, DVD-ROM, DVD-RAM, DVD+R/RW, DVD audio, etc.

The below DVD-Video may not be played back.

- DVD-Video that do not have the region number “1” or “ALL”.
- PAL or SECAM DVD-Video.
- Prohibited or business-use DVD-Video.

CD-R/CD-RWs cannot be played back for the following reasons.

- Compatibility of the disc and this unit.
- Compatibility of the disc and the recorder used.
- Unfinalized discs.

Do not playback the following discs. Playback of these discs may cause a failure.



- Discs on which paper, labels or stickers are affixed.
- Discs that have sticky areas left by adhesive tape.
- Special-shaped discs.

PC-created disc compatibility

Discs recorded using a personal computer may not be playable in this unit due to the setting of the application software used to create the disc. In these particular instances, check with the software publisher for more detailed information.

Discs on which video can be recorded

To record video with this unit, use the discs below:

Media type	Logo mark
DVD-RW Ver.1.0 Ver.1.1 Ver.1.2 Ver.1.1CPRM support Ver.1.2CPRM support	
DVD-R Ver.2.0 (Ver.2.0 /4x /8x)	

DVD-RW

- The disc can be erased and used again about 1,000 times.
- Only the VR mode can be used for Ver.1.0 discs.
- With Ver.1.1/1.2 discs, you can record by selecting the VR mode or Video mode.
- When you record in the VR mode, you can repeatedly record and erase. By erasing unnecessary titles, you effectively increase remaining time.
- When you record in the Video mode, you can record until the disc becomes full.
- When you use the Video mode, you can newly record on the disc by formatting the disc. However, if the disc is formatted, all the recorded contents will be erased.

DVD-R

- You can record on the disc only in the Video mode.
- You can record until the disc becomes full.
- Finalizing the discs allows playback on other DVD players. However, the finalized discs can no longer be recorded.
- Discs can be recorded to repeatedly until they are finalized.



Note

- There are some players that cannot playback discs that were recorded with this unit. We cannot guarantee the playback with other units.
- This unit cannot record on DVD-R and DVD-RW discs that are 8 cm in diameter.
- This unit cannot record on CD-R or CD-RW.

Recording format

This unit has two modes for formatting discs for recording: VR mode and Video mode.

When a blank, new disc is loaded into this unit, the automatic format function starts to format the disc. (For the disc format setting in this step.)

VR mode

- This mode can be used for DVD-RW.
- In this mode, the discs can be recorded and edited repeatedly.
- The disc recorded in this mode can be played back with other DVD -RW-compatible players.
- When a Ver.1.1 CPRM or Ver.1.2 CPRM disc is used, you can record a "Copy Once" program.

Video mode

- This mode can be used for DVD-R and DVD-RW (Ver.1.1/1.2).
- When you finalize the disc after recording, the disc recorded with this unit can be played back with other DVD players.
- Recording, editing or playback of an unfinalized disc can be done only with this unit. However, there is some limitation to editing operations.
- In this mode, you cannot record a "Copy Once" program.
- When you record a TV program of a bilingual broadcast, only one of the audio modes can be recorded. You have to select it.

Format modes that can be used each disc

The usable format depends on the media type as shown in the below table.

Media type	Format	Available functions
DVD-RW Ver.1.0	VR mode	Playback, recording and editing (Original/playlist)
DVD-RW Ver.1.1 and 1.2	VR mode	Playback, recording and editing (Original/playlist)
	Video mode	Playback and recording Editing (with limitation)
DVD-R Ver.2.0 (Ver.2.0/4x/8x)	Video mode	Playback and recording Editing (with limitation)

7.12 CLEANING



Before shipping out the product, be sure to clean the following positions by using the prescribed cleaning tools:


Position to be cleaned	Cleaning tools
Pickup lenses	Cleaning liquid : GEM1004 Cleaning paper : GED-008

Position to be cleaned	Cleaning tools
Fans	Cleaning paper : GED-008


8. PANEL FACILITIES

8.1 FRONT AND REAR SECTION

Front panel




Rear panel



8.2 DISPLAY

Display window




No.	Display	Description
①		Lights during video tape playback.
		Video tape is temporarily stopped.
		Lights during video tape recording.
		Progressive scanning mode.
		Timer recording display.
	XP/SP/LP/SLP	4 DVD recording modes. XP, SP, LP or SLP is selected in turn by pressing the REC MODE/SPEED repeatedly.
	SP/SLP	2 VCR recording modes. SP or SLP is selected in turn by pressing the REC MODE/SPEED repeatedly.
②		Appears when a CD is inserted.
		Appears when a CD-R is inserted.
		Appears when a CD-RW is inserted.
		Appears when a DVD-Video is inserted.
		Appears when a DVD-R is inserted.
		Appears when a DVD-RW is inserted.
	VR	Appears when a DVD-RW in VR mode is inserted. When the disc is set to video mode, VR does not appear.
	VCR	Appears when the tuner built into this unit is selected. When you press TV/VCR, VCR disappears.
		Video tape is in the unit.
③	10:00	Clock display (Colon [:] flashes).
	01H00M00S	Counter display in hour/minute/second for VCR/DVD, minute/second for CD.
	C 36CH	CATV channel display.
	2CH	TV channel display.
	TRK 002	Track number display for CD.
	PM	Display for afternoon (out in the morning).
	L1/L2	The external input channel (L1 or L2) display
	Err	Error display.
④		Lights during playback of DVD and CD. Flashes in auto resume.
		DVD or CD is temporarily stopped.
		Lights during DVD recording.

Note

- Some discs may not playback correctly or chapter number, playback time, etc may not be displayed.

8.3 REMOTE CONTROL

Remote control



1 STANDBY/ON

Turns power on/off

2 VCR EJECT

Ejects the cassette tapes.

3 DVD OPEN/CLOSE

Opens or closes the tray.

4 DVD/VCR

Switches to operation between VCR and DVD.

5 0-9

Use for direct TV channel selection of TV; setting the input entering a password; entering a Pluscode for VCR Plus+ timer programming.

6 TIMER REC

Sets the unit to start recording at a preset time.

7 INPUT SELECT

Switches between the external inputs.

8 VCR Plus+

Display the VCR Plus+ program screen.

9 RETURN

Closes the menu window.

10 CLEAR/CANCEL

Cancels input data in the setting mode; deletes the timer recording program.

11 TITLE MENU/TOP MENU

Selects titles of a DVD disc.

12 CH +/-

Use to select TV channels.

▲/▼

Up/down cursor buttons

13 TRK +/-

Use to adjust the VCR manual playback tracking.

◀/▶

Left/right cursor buttons

14 ENTER/SELECT

Use to select menu options.

15 DVD MENU

Displays the menu of the DVD disc.

16 SETUP

Displays the setup menu.

17 STOP

Stops playback or recording.

18 PLAY

Starts playback.

19 PAUSE/STILL

Pauses recording or playback (press again to restart).

20 SKIP ◀◀ / ▶▶

Skips forward or back chapters.

21 INDEX ◀◀ / ▶▶

Searches for INDEX marks on a tape

22 REW/SEARCH -

Rewind/review playback

23 F.FWD/SEARCH +

Fast forward/forward search playback

24 ONE TOUCH REPEAT

Repeats playback of the last 10 seconds of video.

25 CM SKIP

Skips commercial breaks.

26 SLOW

Starts slow motion playback.

27 REC

Starts recording.

28 REC MODE/SPEED

Selects the recording mode.

29 DUBBING

Copies VCR to DVD or DVD to VCR.

30 AUDIO/AUDIO SELECT

Switches sound between mono and stereo; changes the language of the DVD.

31 DISPLAY/CALL

Displays VCR or DVD operation status.

32 ZOOM

33 REPEAT A-B

Repeats playback between A and B.

34 ZERO RETURN

Stops the tape when the counter reaches 00_H00_M00_S.

35 COUNTER RESET

Resets the counter to 00_H00_M00_S.

36 ANGLE

Changes the DVD playback angle.

37 SUBTITLE

Selects subtitles of the DVD disc.

38 ATR

Digital auto tracking for VCR playback.

39 PLAY MODE

Selects the playback mode.

40 REPEAT

Selects the repeat playback mode.

41 CLOCK/COUNTER

Changes the front panel display mode.

42 TV/VCR

Switches input between the TV and VCR.

43 PROGRESSIVE

Activates the progressive scanning mode.

■

5

■

6

■

7

■

8

■

A

■

B

■

C

■

D

■

E

■

F

■

5

■

6

■

7

■

8

■

DVR-RT500-S

Jigs list

A

Name	Jig No.	Remarks
VHS Alignment Tape	GGV1183	Hi-Fi Audio (For 4 heads mode)
VHS Alignment Tape	GGV1184	X Value Adjustment (For 4 heads mode)
VHS Alignment Tape	GGV1185	EP Monoscope, 6kHz (For 4 heads mode)
Adapter	GGF1506	VSR Torque, Brake Torque (S Reel/T Reel Assy)
Dial Torque Gauge (10-90 gf•cm)	GGF1507	Brake Torque (T Reel Assy)
Dial Torque Gauge (60-600 gf•cm)	GGF1508	VSR Torque, Brake Torque (S Reel)
Post Adjustment Screwdriver	GGF1509	Guide Roller Adjustment
X Value Adjustment Screwdriver	GGF1510	X Value Adjustment
Mater Plane	GGF1511	Reel Disk Height Adjustment
Reel Disk Height Adjustment Jig	GGF1512	Reel Disk Height Adjustment
Torque Tape (VHT-063)	GGV1186	Playback Torque, Back Tension Torque During Palyback

B

C

D

E

F